



Proceedings Relative Free Energy Function and Structural Theory of Thermoeconomics [†]

Antonio Valero * D and César Torres * D

CIRCE Institute, Universidad de Zaragoza, 50018 Zaragoza, Spain

* Correspondence: valero@unizar.es (A.V.); ctorresc@unizar.es (C.T.)

+ Presented at the First World Energies Forum, 14 September–5 October 2020; Available online: https://wef.sciforum.net/.

Published: 11 September 2020



Abstract: This paper explores the advantages of using relative free energy instead of exergy to build a mathematical theory of thermodynamic costs to diagnose malfunctions in thermal systems. This theory is based on the definition of a linearized characteristic equation that represents the physical behavior of each component. The physical structure of the system described by its energy interrelationships is called "primal", and its derivatives are the costs and consumptions. The obtained cost structure is the mathematical "dual" of its primal. The theory explains why the F and P cost assessment rules and any other suggestion may (or may not be) rational under a given disaggregation scheme. A result of the theory is a new thermodynamic function called the relative free energy and a new parameter called deterioration temperature, which due to a component's deterioration cause and is characterized by an h-s thermodynamic trajectory describing the effects on the exiting stream. The relative free energy function allows for an exact relationship between the amount of used resources and the increase in entropy generation caused by the deterioration path of the component. This function allows the obtaining of, for the first time, an appropriate characteristic equation for a turbine and a new definition of efficiency that does not depend on the environmental temperature, but on the deterioration temperature. In addition, cost with relative free energy instead of exergy may open a new path for more precise and straightforward assessments of component deterioration.

Keywords: thermoeconomics; structural theory; characteristic equation; exergy cost theory; relative free energy; deterioration temperature; cost assessment; cost conservation equation; exergy dual/primal; thermoeconomic diagnosis

1. Introduction

The aim of this paper is challenging, since it questions all the concepts that have been traditionally used in thermoeconomics, also called exergoeconomics, by other authors [1]. There is a consensus among practitioners that exergy is the thermodynamic property that best distributes production costs among various streams, which then helps to establish the economic costs of the streams that interact in any energy system. However, the exergy calculation has the shortcoming that it depends on the reference environment employed, which, in turn, is an arbitrary selection of the user and not a physical behavior of the system under analysis. If this is so, the concept of exergy efficiency, although more precise than the first law efficiency, still depends on the reference environment. This obviously also applies to its inverse, the unit exergy consumption, which is the precursor of the Theory of Exergy Cost [2,3]. Efficiency and cost are, in effect, two sides of the same coin.

The Exergy Cost Theory (ECT) is simple to understand and easy to implement computationally, and, as a result, its use has taken off since 1986 when it was first published. A year earlier, G. Tsatsaronis proposed the identification of all the currents of an energy system in fuels and products and, thereby,

the generation of the exergoeconomic costs. The ECT facilitated the task by proposing general fuel–product cost allocation rules that made the costs of energy systems a quasi-routine matter. However, the problem of selecting a reference environment remains, and there might be a consensus regarding which is the most suitable. However, convergent opinions are not mathematical proofs. Moreover, the word thermoeconomics adds an enormous responsibility to the researcher, as it implicitly makes a fundamental connection between thermodynamics and economics.

Historically, many economists, especially the so-called ecological economists, have approached thermodynamics. The work of [4] extensively describes the early connections between economists and energeticists. Perhaps the most rigorous work was that from Georgescu-Roegen [5]. He already discarded energy as a numeraire, pointing to entropy instead. He even went beyond by formulating the fourth law of thermodynamics as the impossibility of complete recycling of materials, drawing a parallel with the second law as the impossibility of complete recycling of thermal energy. From there on, ecological economists have tried to use entropy more as a metaphor than as a tool that quantifies decisions.

On the other hand, thermodynamicists, mainly engineers, developed the concept of exergy. It is not the aim of this paper to describe the history (see [6]), but to outline the conceptual roots of thermoeconomics. Exergy measures the theoretical ability to do work; therefore, exergy efficiency will more precisely measure the performance of a machine. However, the inverse of the efficiency describes the amount of resources consumed to obtain a product. This is actually the definition of the physical cost, which, in turn, stands on the threshold of the economics. This is so because if we value resources in monetary units and add other costs, such as equipment depreciation, maintenance, and other expenses, one obtains the monetary costs of production not only of the final products, but also of the intermediate products [1,7,8]. This opened the door to comparing the costs of irreversibilities against the costs of operation and maintenance, which, in turn, naturally lead to the proposal of improvements in the design of industrial processes. This was a paramount technological breakthrough.

Arguably, practicality, not mathematical precision, is what is sought in exergoeconomic cost analysis because the cost is measured in monetary units. That said, the fluctuation of money is alien to the process designer, since it depends on external conditions that the practitioner cannot control. Consequently, exergoeconomics is a useful tool in the design of industrial processes, but it does not strive for the same precision associated with physical sciences. Its results depend both on the variability of money and on the measurement of irreversibilities with respect to the chosen reference state.

The question is whether to go back to the concept of exergy cost, which only measures how the physical resources consumed by the production plant are distributed. In so doing, one at least avoids currency fluctuations and focuses on the diagnosis of malfunctions that occur in all industrial processes [9]. This opened a new technological path because no energy system deteriorates for a single cause, but for several at the same time with different intensities and with chains of causation that induce new malfunctions and dysfunctions. Thermoeconomic diagnosis, using exergy costs, can be applied on-line and is very useful when analyzing very complex plants. The disaggregation of any industrial energy system into subsystems allows understanding of the process of the formation of physical costs, predicts failures, and may keep the plant in optimal operating conditions. However, the costs of malfunctions are still dependent on the reference state of the plant, which can be taken as fixed or variable depending on external environmental conditions.

In other words, exergy is useful as an industrial diagnosis tool; equipment malfunction is essentially due to deterioration of the equipment itself, not to the definition of the reference environment. In short, exergetic diagnosis is not a precise and objective physical theory, but a very useful tool, as agreed upon by practitioners. The question now is: Is there an exergy-like function that could provide diagnoses independently from the reference state? This would mean that environmental conditions would, for sure, influence the industrial system, not because of an arbitrary designer's selection, but through the environment's own natural interaction with the process.

If this were possible, we could give a rigorous answer not only to the thermodynamics of energy systems, but to the economics themselves, and all without leaving the second law. Linking the concept of cost with thermodynamics is to bridge the gap between physics and economics. It would be a crucial conceptual step forward sought by economists, something like the Holy Grail of economics. Indeed, while economists have come a long way in mathematical applications, they have never been able to link their laws to any physical law, except for metaphors and analogies. In this way, the conventional separation between hard and soft sciences would be closer to a scale of hardness than to the hard/soft dichotomy.

This paper expands upon an early keynote lecture at Nancy University [10], and its objective is to come closer to a solution to this problem and investigate the concept of relative free energy already proposed by Valero et al. [11], but with important precursors, such as Baehr [12] and Alefeld [13]. To maintain the completeness of the work, the Theory of Exergy Cost is briefly described first, followed by the Structural Theory [14]. This leads to analyzing whether the decisions made by the process analyst are or are not supported by mathematical logic. These decisions are mainly the cost allocation rules, the level of aggregation, the fuel/product/waste definitions, and, of course, the exergy function and the reference state. This will allow the discernment of mathematical reasons from reasonable assumptions and will go forward to a new thermodynamic function: the relative free energy function.

2. The Exergy Cost Theory

The exergy cost (kWh), otherwise known as cumulative exergy consumption [15,16] or presently adopted as embodied exergy, according to some authors, measures the amount of exergy necessary to manufacture a product when the boundaries of the production plant, disaggregation level, and exergy efficiency of each component have been defined [2,3]. Herein, the exergy cost of a stream with exergy *Ex* is denoted with an asterisk, Ex^* , and its unit exergy cost is expressed as follows: $k^* \equiv Ex^*/Ex$.

The process of cost allocation in productive systems requires a set of rules [3,17]:

Resources Rule: The exergy cost of the flows entering a thermal system should be provided as input data. In the absence of further information, it can be assumed as equal to their exergy.

Cost Conservation Rule: For each and every system component, the exergy cost of output flows is equal to the exergy cost of the input flows.

Unspent Fuel Rule: Known as Rule *F* as well. The unit exergy cost of unspent fuel at the output of a system component is the same as that of the input fuel.

Co-products Rule: Known as Rule *P* as well. All products of the same quality at the exit of a system component have the same unit exergy cost.

There are other cost rules dealing with special cases, particularly the case of wastes, by-products, condenser outlets, etc., which are outside of this short description of the outlined theory [18].

In summary, the (average) exergy cost is a conservative property, and the production cost must be allocated to what one wants to produce. Therefore, when a process has multiple outputs, Rules *F* and *P* need to be applied (see Figure 1) depending on the productive purpose of the processes.

Let us see an example of application of these rules. Suppose, first, a medium-pressure steam turbine, as shown in Figure 2, where the entering steam F_1 has 30 MW of exergy, it delivers a shaft work of P = 10 MW, and the exit steam F_2 still has 19 MW of exergy. Then, the exergy expended to produce P is $F_1 - F_2 = 11$ MW, and its efficiency $\eta = P/(F_1 - F_2) = 0.909$.

If the turbine's objective is to produce power, the full cost of that product should be charged to the shaft work. Accordingly, the Rule *F* means that the unit exergy cost of the flowing steam remains unaltered. Suppose that the amount of exergy expended to produce the entering steam is 2.5 times greater than its exergy content, i.e., $k_1^* = 2.5$ MW/MW. Then, the Rule *F* states that the unit exergy cost of the exit steam, F_2 , is that of the entering steam, F_1 , or $k_2^* = k_1^* = 2.5$ Consequently, the amount of exergy needed to produce the shaft work will increase in $k_3^* = k_1^*/\eta = 2.75$ MW/MW.

To explain Rule *P*, consider an electric generator added to a distributor, as in Figure 3. It delivers two currents—9 MW of net energy output and 0.5 MW for ancillary systems—at the expenditure of 10 MW of shaft work. Its efficiency becomes $\eta = (P_1 + P_2)/F = 0.95$. As both outlet streams are simultaneously required, the cost of its production must be allocated proportionally to both currents. Therefore, the Rule *P* states that the exergy cost per unit of exergy must be equal for the two currents. If the unit exergy cost of the shaft work was $k_1^* = 2.75$ MW/MW, then the unit costs of the output electric streams become $k_2^* = k_3^* = k_1^*/\eta = 2.895$ MW/MW. The reader may find many examples of applications of these rules to a wide-ranging class of thermal systems in [19].



Figure 1. Cost allocation Rules *F* and *P* in stream bifurcation.

As can be seen in this simple example, these rules link the concepts of the unit exergy cost, k^* , of the streams with the efficiency definition of the system's components, $\eta = 1/k$, one to one, where k is named the unit exergy consumption of the component. In other words, the cost of the final product increases as irreversibilities accumulate. If these increase, the efficiency of the components decreases and the costs increase accordingly. Thus, there is a direct connection between efficiency, cost, and irreversibility when exergy is used as a measure of the energy flows of thermal systems. This is the essential message of the Theory of Exergy Cost, which has been extensively used to assess the costs of many thermal systems.

However, a number of questions have arisen. First, based on its definition, the exergy cost depends on the plant disaggregation scheme. In other words, it cannot render a precise value because it depends on the analyst's choice. For instance, a chemical plant produces ethylene and electricity, which are not produced in the same process, but in the same plant; hence, either Rule *P* or Rule *F* could be applied. Therefore, the formation and type of the streams and how much and where the exergy has been consumed in the process must be analyzed. This detailed analysis provides a productive structure to which the rules can be applied in practical terms. A more detailed definition is more precise; however, there is the risk of not having measured data that corroborate the sensitivity of the obtained costs to variations in these data. There can be major discrepancies among practitioners regarding the definition of productive structures and the disaggregation method of the processes.

Second, the definition of exergy efficiency also depends on the analyst. For example, in a counter-current heat exchanger, a stream becomes cooled, and another becomes heated. Hence, it heats, cools, or both; then, which stream assumes the production cost? Furthermore, not all components

aim to save exergy (productive components). Certain other components in a plant are responsible for mitigating (the exergy of) wastes. Hence, how to allocate costs to the components that process residues must be determined. Third, exergy and its related cost depend on the chosen reference environment. However, the physical behavior of the plant does not depend on the analyst's choice. Additionally, the right choice of the energy-like function for describing the plant might be in doubt: energy, exergy, (Gibbs) free energy, or any other generic function.

Moreover, are the obtained costs average costs or marginal costs? The exergy of a stream measures its potential work with respect to a given environment, and the exergy cost measures how many irreversibilities have occurred in the manufacture of a stream or product plus its remaining exergy. The exergy cost can be considered an "exergy backpack" or "exergy footprint" of a stream or product, i.e., the past exergy synopsis (history) of the stream, whereas its exergy is the future energy potential of such a stream or its remaining capacity to produce work. Finally, can the exergy costs predict future degradations or describe only past irreversibilities?

Despite these doubts, the analyst aims to obtain reasonable costs. Thus, it is necessary to disaggregate the system as far as common sense advises. However, if costs depend on the disaggregation scheme, what scheme is reasonable? Second, the definition of efficiency for each component requires caution. Is it possible to find a more rational definition of efficiency? Third, choosing exergy is apparently better than other energy-like functions because it provides a proxy for the locally usable energy. Are there better energy-like functions that predict the behavior of components? Fourth, the selected reference level for exergy must be realistic. Is it possible to avoid the dependence of costs from the chosen reference environment? Finally, the average costs should be useful in predicting how many additional resources compensate for the small system perturbations. Is there a theory capable of predicting small system perturbations exactly? While the current theory does not support these prudent conventions, practice does.

3. On the Linearity of Cost: The Structural Theory of Thermoeconomics

Any energy system that consumes resources and manufactures products can be characterized by a thermodynamic function *E* of the generic type, $E = m(h - T_x s)$, where *m* is the mass, *h* the enthalpy, *s* the entropy with respect to a certain reference, and T_x the temperature to choose under certain conditions. When T_x is zero, the function *E* is the enthalpy; when T_x is the ambient temperature, *E* is the exergy; if T_x is the temperature of the system, *E* is the Gibbs free energy function.

The mathematical behavior of any component *u* can be described through functions of the type:

$$E_i = g_i\left(\{x\}, \{E_i\}\right) \qquad i \in \mathcal{E}_u,\tag{1}$$

where $i \in \mathcal{E}_u$ are the input flows of component $u, j \in \mathcal{S}_u$ are the output flows of component u, and $\{x\}$ is the set of internal governing parameters, such as internal efficiencies, pressure relationships, temperature increases, geometric parameters, structural parameters, fluid-dynamic parameters, or heat-transfer parameters. If the system environment is considered as the component "0", then \mathcal{E}_0 is the set of the system outputs, and \mathcal{S}_0 is the set of input resources to the system.

Equation (1) does generally not relate inputs and outputs linearly. Because the only degree of freedom is the choice of T_x (i.e., the choice of energy, exergy, Gibbs function, or any other function), it is likely that the complexity of the equation cannot be reduced to a linear relationship. However, such a continuous function allows for a Taylor series approximation. In addition, by choosing sufficiently small linear intervals, second-order terms can be discarded. The smaller the interval, the closer the proposed behavior is to reality. By applying this step, the following is obtained:

$$E_{i} = \begin{cases} \sum_{j \in \mathcal{S}_{u}} k_{ij}(x) E_{j} & i \in \mathcal{E}_{u} \\ \omega_{i} (const.) & i \in \mathcal{E}_{0} \end{cases},$$
(2)

which relates the inputs and outputs linearly through parameters k_{ij} , which substitute the internal parameters for each identified component. Furthermore, the coefficients k_{ij} take the name of technical production coefficients in the input–output theory [20]. They are the (average) unit consumption of resource *i* necessary to produce stream *j*.

Owing to the linearity, the coefficients k_{ij} coincide with derivatives (ceteris paribus) of the following type:

$$k_{ij} \equiv \frac{\partial E_i}{\partial E_j}.$$
(3)

The advantage of a linear analysis is that it enables the understanding of many underlying assumptions in any cost allocation theory:

$$E_i = \sum_{j \in \mathcal{S}_u} \left(\frac{\partial E_i}{\partial E_j} \right) E_j \qquad i \in \mathcal{E}_u.$$
(4)

Herein, this expression is called the component's characteristic equation.

On the other hand, the globally considered plant will receive some resources, E_0 , defined as:

$$E_0 = \sum_{j \in \mathcal{S}_0} E_j,\tag{5}$$

where S_0 is the set of flows entering the plant (or leaving the environment).

The cost allocation is a basic application of the chain rule for derivative calculation, which is independent of if the characteristic equations are linear or not; then, the following expression for each flow of the system is satisfied:

$$\left(\frac{\partial E_0}{\partial E_j}\right) = \sum_{i \in \mathcal{E}_u} \left(\frac{\partial E_0}{\partial E_i}\right) \left(\frac{\partial E_i}{\partial E_j}\right).$$
(6)

If we identify the marginal unit cost with the derivative:

$$k_i^* \equiv \left(\frac{\partial E_0}{\partial E_i}\right),\tag{7}$$

the marginal unit cost of flows could be determined by means of Equation (6) as follows:

$$k_j^* = \begin{cases} \sum_{i \in \mathcal{E}_u} k_i^* k_{ij} & j \in \mathcal{S}_u \\ 1 & i \in \mathcal{S}_0 \end{cases}$$
(8)

In other words, the unit cost of outputs of process *u* is linearly related with the unit cost of input streams by means of the technical coefficients. In the case of the system's inputs, the marginal costs are known or made equal to one, which corresponds to the external resources rule in the Exergy Cost Theory.

The application of this equation explains the previously mentioned Rules *F* and *P* as a particular case. For example, a turbine (Figure 2) with the following defined efficiency is considered.



Figure 2. Conventional efficiency definition of a turbine as an example of the application of Rule F.

Suppose now that it is assumed that the characteristic equation of the turbine coincides with the exergy definition of the turbine. In the simulations of the turbine for a reasonably small working interval, k can be considered constant. By applying the unit cost in Equation (8), the costs of outputs #2 and #3 are obtained:

$$k_3^* = k k_1^*$$
 and $k_2^* = k_1^*$. (9)

Hence, the result is Rule *F*, i.e., if a resource has not been totally consumed (stream 2), its unit cost is equal to that of the input resource (stream 1).

However, if a typical electric power distribution system is considered (see Figure 3), its efficiency can be expressed as follows.



Figure 3. Generic electric power distribution system as an example of application of Rule P.

Again, it is assumed that the characteristic equation of the distribution system coincides with its exergy definition. If k is constant, applying the unit cost in Equation (2) results in:

$$k_2^* = k k_1^*$$
 and $k_3^* = k k_1^*$, (10)

which explains why Rule *P* applies; that is, the unit costs of the products of the same nature produced in the same process are equal.

In general, the disaggregation of the process in Figure 4 can be described by the following system of characteristic Equation (11):

$$\begin{cases}
E_1 = k_{12} E_2 + k_{13} E_3 \\
E_2 = k_{24} E_4 + k_{26} E_6 \\
E_3 = k_{35} E_5 \\
E_4 = \omega_4 \quad \text{(const.)}
\end{cases}$$

$$\begin{cases}
E_1 = \left(\frac{\partial E_1}{\partial E_2}\right) E_2 + \left(\frac{\partial E_1}{\partial E_3}\right) E_3 \\
E_2 = \left(\frac{\partial E_2}{\partial E_4}\right) E_4 + \left(\frac{\partial E_2}{\partial E_6}\right) E_6 \\
E_3 = \left(\frac{\partial E_3}{\partial E_5}\right) E_5 \\
E_4 = \omega_4 \quad \text{(const.)}
\end{cases}$$

$$\begin{aligned}
E_5 = \omega_5 \quad \text{(const.)} \\
E_6 = k_{65} E_5
\end{cases}$$

$$\begin{cases}
E_1 = \left(\frac{\partial E_1}{\partial E_2}\right) E_2 + \left(\frac{\partial E_1}{\partial E_3}\right) E_3 \\
E_2 = \left(\frac{\partial E_2}{\partial E_4}\right) E_4 + \left(\frac{\partial E_2}{\partial E_6}\right) E_6 \\
E_3 = \left(\frac{\partial E_3}{\partial E_5}\right) E_5
\end{cases}$$

$$\begin{aligned}
E_6 = k_{65} E_5
\end{aligned}$$

$$\begin{cases}
E_1 = \left(\frac{\partial E_1}{\partial E_2}\right) E_2 + \left(\frac{\partial E_1}{\partial E_3}\right) E_3 \\
E_2 = \left(\frac{\partial E_3}{\partial E_5}\right) E_5
\end{cases}$$

$$\begin{aligned}
E_6 = \left(\frac{\partial E_6}{\partial E_5}\right) E_5
\end{cases}$$

$$\begin{aligned}
E_7 = \left(\frac{\partial E_6}{\partial E_5}\right) E_5
\end{aligned}$$



Figure 4. Generic energy system.

Subsequently, according to the rule of the chain of the derivatives, the following expressions are obtained:

$$\begin{cases} \left(\frac{\partial E_{0}}{\partial E_{1}}\right) = 1 \\ \left(\frac{\partial E_{0}}{\partial E_{2}}\right) = \left(\frac{\partial E_{0}}{\partial E_{1}}\right) \left(\frac{\partial E_{1}}{\partial E_{2}}\right) \\ \left(\frac{\partial E_{0}}{\partial E_{3}}\right) = \left(\frac{\partial E_{0}}{\partial E_{1}}\right) \left(\frac{\partial E_{1}}{\partial E_{3}}\right) \\ \left(\frac{\partial E_{0}}{\partial E_{4}}\right) = \left(\frac{\partial E_{0}}{\partial E_{2}}\right) \left(\frac{\partial E_{2}}{\partial E_{4}}\right) \\ \left(\frac{\partial E_{0}}{\partial E_{5}}\right) = \left(\frac{\partial E_{0}}{\partial E_{3}}\right) \left(\frac{\partial E_{3}}{\partial E_{5}}\right) + \left(\frac{\partial E_{0}}{\partial E_{6}}\right) \left(\frac{\partial E_{6}}{\partial E_{5}}\right) \\ \left(\frac{\partial E_{0}}{\partial E_{6}}\right) = \left(\frac{\partial E_{0}}{\partial E_{2}}\right) \left(\frac{\partial E_{2}}{\partial E_{6}}\right) \\ \left(\frac{\partial E_{0}}{\partial E_{6}}\right) = \left(\frac{\partial E_{0}}{\partial E_{2}}\right) \left(\frac{\partial E_{2}}{\partial E_{6}}\right) \end{cases}$$
or
$$\begin{cases} k_{1}^{*} = 1 \\ k_{2}^{*} = k_{1}^{*} k_{12} \\ k_{3}^{*} = k_{1}^{*} k_{13} \\ k_{4}^{*} = k_{2}^{*} k_{24} \\ k_{5}^{*} = k_{3}^{*} k_{35} + k_{6}^{*} k_{65} \\ k_{6}^{*} = k_{2}^{*} k_{26} \end{cases}$$

$$(12)$$

Equation (2) can be rewritten in the matrix form:

$$\mathbf{E} = [\mathbf{K}] \ \mathbf{E} + \mathbf{\Omega},\tag{13}$$

where [K] is the matrix of unit consumption, and Ω is the vector of the system's output values; Equation (8) becomes:

$$\mathbf{k}^* = {}^{\mathsf{t}} \left[\mathbf{K} \right] \, \mathbf{k}^* + \mathbf{k}_0^*, \tag{14}$$

where \mathbf{k}_0^* is the unit cost of the system's input flows. In the analyzed case, these matrix variables are:

Please note that the matrix of the unit consumption [K] is common and transposed between Equations (13) and (14). Equation (13) is the primal model of the structure, and Equation (14) is its dual model. Every productive structure or linear input–output interpretation of a system exhibits a primal representation with a corresponding dual and vice versa [21].

Figure 5 shows the dual cost structure of system in Figure 4. While the arrows in the productive process (primal) point from the resources toward the products, the cost structure (or dual) points from the products toward the resources. The costs search for the origin (causa materialis), while the products search for the final objective (causa finalis) [22].



Figure 5. Dual cost structure of generic plant in Figure 4.

The cost of the productive structure is a conservative property, which is to say, the costs of the inputs of any component are entirely transferred among the outputs (Equation (15)). This is a mathematical consequence of the founded hypotheses:

$$\sum_{i\in\mathcal{E}_u} E_i^* = \sum_{j\in\mathcal{S}_u} E_j^*.$$
(15)

For instance, the case of component #1 is chosen, and the input equation

$$E_1 = k_{12} E_2 + k_{13} E_3$$

is combined with its output equations, $k_2^* = k_{12} k_1^*$ and $k_2^* = k_{12} k_1^*$; consequently:

$$k_1^* E_1 = k_2^* E_2 + k_3^* E_3.$$

In general, applying Equations (2) and (8) to Equation (15), the cost balance is satisfied:

$$\sum_{i \in \mathcal{E}_u} k_i^* E_i = \sum_{i \in \mathcal{E}_u} k_i^* \sum_{j \in \mathcal{S}_u} k_{ij} E_j = \sum_{j \in \mathcal{S}_u} \left(\sum_{i \in \mathcal{E}_u} k_i^* k_{ij} \right) E_j = \sum_{j \in \mathcal{S}_u} k_j^* E_j,$$
(16)

and the cost balance for the global plant will be:

$$E_0 = \sum_{i \in \mathcal{E}_0} k_i^* E_i.$$
(17)

Therefore, the plant's incidence matrix A can be defined as:

$$a_{ij} = \begin{cases} 1 & \text{if } j \in \mathcal{E}_i \\ -1 & \text{if } j \in \mathcal{S}_i \\ 0 & \text{otherwise} \end{cases}$$
(18)

Hence, the analyzed case can be described as follows:

In general, the following expression holds:

$$\mathbf{A} \cdot \mathbf{E}^* = \mathbf{0},\tag{19}$$

and Equation (19) shows the cost conservation rule. This is a mathematical consequence of the founded hypotheses.

ł

This result is quite remarkable because the following equations straightforwardly summarize the equilibrium thermodynamics for open systems:

$\mathbf{A} \cdot \mathbf{M} = 0$	Mass Balance	(20)
$\mathbf{A} \cdot \mathbf{H} = 0$	Energy Balance	(21)
$\mathbf{A} \cdot \mathbf{E}\mathbf{x} = \mathbf{I}$	Exergy Balance	(22)
$\mathbf{A}\cdot\mathbf{E}\mathbf{x}^*=0$	Cost Balance,	(23)

where **M**, **H**, and **Ex** are the mass, enthalpy, and exergy vectors of the material streams m_i , $m_i h_i$, and $m_i(h_i - T_0 s_i)$ if there are the heat flows *zero*, Q, and $Q(1 - T_0/T)$, or *zero*, W, and W if there are working flows, respectively. Note the parallelism with respect to the balance cost (Equation (19)). The presented structural theory explains the previously presented Exergy Cost Theory.

4. Outcomes

The presented theory mitigates several important deficiencies of the conventional Exergy Cost Theory. First, its results do not depend on a disaggregation scheme. For example, the system in Figure 4 is aggregated into a single component (Figure 6).



Figure 6. Aggregated system of Figure 4.

The physical behavior of the system remains (if linearized) the same under Equations (1) and (2). However, neither the Rule *P* nor Rule *F* can be applied between streams #4 or #5. In other words, k_4^* is not equal to k_5^* , nor to k_1^* . Therefore, the theory provides many hints about how to explore the cost relationships and suggests that greater disaggregation schemes are required.

The main idea originates from the difference between the characteristic equation and the efficiency equation (e.g., Figure 2 or Figure 3). The former reflects the physical behavior of the component, while the second is a definition, (i.e., an identity). For instance, the linear characteristic equation of Figure 6 is expressed as follows:

$$E_1 = k_{14} \, E_4 + k_{15} \, E_5.$$

Meanwhile, its efficiency equation could be of the following type:

$$Ex_1 \equiv k Ex_4 + Ex_5.$$

The similarity is evident; however, the more the analyst aggregates, the more the physical behavior of the system deviates from the aggregated efficiency definition. Note also that the reference environment of the exergy depends on the practitioner's choice, whereas Equation (2) should be independent.

The structural theory, first presented in [14,23], has been largely ignored in the study of different and alternate rules for cost allocations, such as in the allocation of the costs of wastes or by-products. This might be due to the difficulties of determining the fundamental equations of components, such as in Equation (1), or their linearized equations, such as in Equation (2). Rather, the theory has been used to check the logic of Rules *F* and *P*.

Please note that Odum's Emergy Analysis [24,25] does not satisfy Equation (19) because it considers that when a biological system produces two products simultaneously, the same amount of solar energy is required for each product. This does not deny the idea of emergy; it simply states that this is not a regular cost.

In the same way, a non-linear theory does not satisfy Equation (4) because the primal would be of the following type:

$$dE_i = \sum_j \left(\frac{\partial E_i}{\partial E_j}\right) dE_j,\tag{24}$$

rather than as Equation (19). However, Equation (24) enables a generalization of the theory. For example, in [23], the costs are the Lagrange multipliers of an optimization of the plant.

The structural theory formally relates to the input–output theory [20]; however, the characteristic equation makes the difference because it deeply connects the thermodynamic behavior of an energy system to the stream costs, such as in a transparent box. Instead of the economic performance of highly aggregated economic sectors, their input–output flows are obtained outside the black boxes that constitute each sector of the economy. In addition, the second law exergy analysis appears as a natural connection between physical behavior and cost because it locates and accounts for irreversibilities occurring in a plant; thus, it relates the physical losses to the costs. Please note that "cost" is a concept that originates from economics, while "irreversibility" originates from thermodynamics. The structural theory can be considered a sought-after bridge between classical economics and physics. Thus, we consider the term "thermoeconomics" more appropriate than alternatives such as exergoeconomics [17].

5. Drawbacks of Exergy

One important result of the structural theory is that any energy function of the type $E = H - T_x S$ may be used to assess different sets of costs. Thus, why should exergy, which uses a fixed T_0 instead of a variable T_x , be considered? The most important objective of this study is to question the exergy directly to assess costs.

Mythologizing exergy is not convenient; it only measures the number of times that a product is potentially equivalent to another. Therefore, the kilograms of natural gas, mass of steam at a certain temperature and pressure, and kinetic, magnetic, or mechanical energies are possible units for measuring exergy. Certainly, it does not reflect the product value. A broken glass has practically the same exergy as a new one, and the exergy of gold at T_0 is zero as taken by reference. Moreover, everybody would prefer 1 g diamond over 1 g pure graphite, even though they practically have the same exergy.

In addition, the manufacture of a continuous or broken thread costs the same exergy, although the latter would not be sellable. Exergy reduces a probably irreducible object to a single numerical value. The color, taste, form, texture, or artistic impression (i.e., properties that human beings value) have no distinguishable exergy. The exergy and exergy cost are only a measure of reality, which should not supplant other possible analyses. Can the concept of value be assessed by thermodynamics? Does it make sense to go beyond the exergy cost when it comes to knowing the costs of objects? It has been claimed many times that exergy is a measure of the quality of things, which is false; it is a measure of the energy imbalance that a system has with respect to a reference environment. It is a measure of the thermodynamic quality of energy and not of objects. Moreover, the quality specification is much more complex. A dose of carbon monoxide may have the same exergy as a certain amount of food; however, everybody knows which one to ingest or burn in a boiler. The same food can present a disgusting or an extraordinary aspect and contain the same amount of exergy. Based on the many possible examples, it seems strange to confuse exergy with quality.

Assessing thermodynamic quality requires many specifications, such as the pressure, temperature, composition, height, and speed. Quality also depends on the context, whereas exergy does not. In general, thermodynamic equivalence is not a measure of the equivalence of values. Even circumstances and the moment make a thing seem more or less valuable. Researchers should distance themselves from neo-energeticism (or, even better, "exergeticism"), which regards exergy as a measure of the value of objects rather than as their monetary value. The exergy and exergy costs provide complementary information on the human footprint on Earth; ignoring them is as dangerous as extolling them as a unique instrument for managing the natural resources and environment.

Furthermore, the second law has not exhausted its message regarding exergy. The following equation,

$$F - P = I + R, (25)$$

identifies product, waste, and what is (or is not) a usable resource. Certainly, every real-world process experiences an irreversibility. The Gouy–Stodola theorem relates entropy generation to irreversibility:

$$I = T_0 S_g. aga{26}$$

Regardless of the way the quality of every stream, product, or service is defined (generalized exergy function), it is easier to identify the quantity. Thus, the magnitude of a property X is always a product of its quantity q_x multiplied by its specific quality x:

$$X = q_x \cdot x. \tag{27}$$

It would be interesting to determine the amount of resources required to compensate for a deterioration of any component in a constant production for a set of quality specifications for each flow interacting in a system.

6. The Relative Free Energy Function

Before generalizing the problem, a simple case should be analyzed: For example, the expanding flow of a turbine produces work on the shaft. In an (h, s) diagram (Figure 7), the actual process evolves from state 1 to state 2.

The energy and entropy balances of the process (first and second laws) are as follows:

$$W = m (h_1 - h_2)$$
(28)

$$S_g = m \left(s_2 - s_1 \right). \tag{29}$$

If the turbine degrades at a rate equal to the specifications of the inflow #1, an increase in the entropy generation evidently results in an increase in the amount of entering fuel (path 1) to keep the production constant. Owing to the degradation, the new state of the outflow #2' is characterized by $(h_{2'}, s_{2'})$. A differential analysis under the conditions W=const., h_1 =const., and s_1 =const. leads to the following expressions:

$$(h_1 - h_2) \, dm = m \, dh_2 \tag{30}$$

$$(s_2 - s_1) \, dm + m \, ds_2 = dS_g. \tag{31}$$



Figure 7. The deterioration path of a turbine.

Subsequently, if the deterioration temperature of flow #2 is defined as a quotient:

$$T_{d_2} \equiv dh_2/ds_2$$

the result is as follows:

$$\left(\frac{dm}{dS_g}\right)_r = \frac{T_{d_2}}{(h_1 - h_2) - T_{d_2} \ (s_1 - s_2)} , \tag{32}$$

where *r* is the deterioration path, as shown in Figure 7.

Equation (32) is the mathematical expression of the existing relationship between any local degradation and the increase in associated resources if the production of the component should remain constant.

These equations and the function $\ell \equiv (h_1 - h_2) - T_d(s_1 - s_2)$ were presented in [11]. Valero called it the relative free energy [26,27], and T_d the deterioration temperature (in 1994, Prof. E. Sciubba proposed that it should be named the "dissipation" temperature; however, the authors consider the word "deterioration" more precise, since that word always relates to a component rather than to a process).

The expression "relative free energy" (RFE) originates from its similarity to the Gibbs free energy function. Equation (32) states that any deterioration process in an energy component has an associated T_d in the exit stream of supplying fuel. This parameter possesses temperature dimensions even if it is not a gauging temperature; it can be calculated by measuring the quotient dh_2/ds_2 experienced by the output stream of the component's fuel.

The heat exchanger in Figure 8 experiences the same procedure. In that case, the enthalpy and entropy balances are written as follows:

$$m_1(h_1 - h_2) - m_3(h_4 - h_3) = 0$$
(33)

$$m_1(s_1 - s_2) - m_3(s_4 - s_3) = -S_g.$$
(34)

production; thus, m_3 , (h_3, s_3) , and (h_4, s_4) are constant. Owing to the degradation, the new state of outflow #2' is characterized by $(h_{2'}, s_{2'})$.



Figure 8. Deterioration path of the heat source in a heat exchanger.

A differential analysis under the condition (h_1, s_1) is constant, leading to:

$$(h_1 - h_2) \, dm_1 = m_1 dh_2 \tag{35}$$

$$dS_g + (s_1 - s_2) \, dm_1 = m_1 ds_2. \tag{36}$$

If the dissipation temperature of flow #2 is defined as a quotient:

$$T_{d_2} \equiv \frac{dh_2}{ds_2} > 0$$

Subsequently, Equation (32) is also satisfied.

According to the second law, dS_g is always positive; therefore, more fuel must be used to obtain the same product, and dm > 0. Because $T_{d,2}$ is positive, the term $(h_1 - h_2) - T_{d,2}(s_1 - s_2)$ must be positive; in other words, $T_{d,2}(s_1 - s_2)$ is always lower than $h_1 - h_2$. Note also that, in a low-pressure steam turbine of a Rankine cycle, $T_{d,2}$ coincides with the condenser temperature, which is fully logical. More examples could be found in [27].

7. The h-s Deterioration Path(s) of an Energy System

Man-made energy systems transform the energy flows into other flows with a purpose. Commonly, the name of a component describes its function: A boiler boils water, a condenser condenses steam, and a heat exchanger exchanges heat. The understanding of how nature behaves is the basis of the component design. The entering flow performs a purposive path through which its thermodynamic properties change progressively until the flow exits the component. This path is never strictly determined, either because of possible changes in the quantity/quality of the entering flow or because of changes in the behavior of the component itself. This path variation results in a change in the properties of the exiting flow with respect to its design conditions. There are as many new exit states as causes of change, which are called "malfunctions" and are classified into two categories: intrinsic and induced [28–30]. The term "intrinsic" refers to the internal deterioration of the component; the term "induced" refers to its off-design conditions. Literature and some manufacturers provide governing equations and control parameters based on semi-empirical models of the machines.

For a given deterioration cause *r* of an energy component, either intrinsic or induced, a geometric path in the h - s plane of the possible exit flow states can be identified. Let $h_{2'} = h_{2'}(s_{2'}, r)$ be the function describing this dissipation path of the exiting flow, as in Figure 7, where:

- $1 \longrightarrow 2$: is the design path of the stream in the component.
- $1 \longrightarrow 2'$: is the stream path after the component deterioration.
- $2 \longrightarrow 2'$: is the dissipation path of the exiting stream $h_{2'} = h_{2'}(s_{2'}, r)$.

The function $h_{2'} = h_{2'}(s_{2'}, r)$) can be regarded as the mathematical description of the effects on the exiting flow caused by the component deterioration cause r. This function always exists for a given differential malfunction interval. Moreover, under actual machine conditions, this function is a composite curve of the different paths caused by the concurrent deteriorations acting simultaneously on the component [28]. The next section focuses on this function.

8. The Legendre Transform of a Deterioration Path

For each deterioration cause, r, the existence of a function h = h(s) of the exiting flow can be assumed, which can be described in the h - s plane with the conventional point geometry or Plücker line geometry for strictly convex functions as a convolution of the tangents of the original curve. This technique is named the Legendre transform of the function h = h(s) and is widely used in classical thermodynamics [31,32]. As shown in Figure 9, the intersection of the tangent line of the deterioration path r with the h axis is ℓ and its slope is T_d :

$$T_d = \frac{h-\ell}{s},$$

or

$$\ell = h - T_d s \quad \text{ i.e., } \quad \ell = \ell(T_d). \tag{37}$$



Equation (37) is the Legendre transform of the deterioration path $h_{2'} = h_{2'}(s_{2'}, r)$. In fact, pairs of $(\ell_{2'}, T_{d,2'})$ for each exit state, #2', of the component provide the same information as pairs of $(h_{2'}, s_{2'})$. Since the relationship $\ell_{2'} = \ell_{2'}(T_{d,2'})$ is mathematically equivalent to the relationship $h_{2'} = h_{2'}(s_{2'}, r)$, it can also be considered the description of the deterioration path. More generally, $h_r = h_r(s_r)$ is the deterioration function in the h-representation, whereas $\ell_r = \ell_r(T_d, r)$ is the deterioration function function in the ℓ representation. In other words, ℓ_r and $T_{d,r}$ are inseparable in a deterioration path, r, as are h_r



and s_r . Note also that h and s do not represent absolute values because they refer to h_0 and s_0 values. Unless otherwise stated, h and s represent $h - h_0$ and $s - s_0$.

According to the definition of relative free exergy (Equation (37)), Equation (32) could be written as:

$$\left(\frac{dm}{dS_g}\right)_r = \frac{T_d}{\ell_1 - \ell_2}.$$
(38)

The deterioration temperature, T_d , is not a physical temperature; it is a parameter and derivative with temperature dimensions:

$$T_d = \left(\frac{dh}{ds}\right)_r.$$
(39)

It can be interpreted as the entropic cost of the deterioration. The greater the T_d , the lower the relative free energy of the exiting flow. Well-known contributors to technical thermodynamics such as Baehr [12] have defined the "friction work" or "loss work" for an expander as follows:

$$dW_r = T_d \, dS_g. \tag{40}$$

This loss work is energy that has not been dissipated into the environment at T_0 and contributes to the degradation of the exiting flow of the expander. It increases the enthalpy and entropy of the exiting stream and reduces the work produced by the turbine, thereby decreasing its efficiency.

In the example of the turbine (Figure 7), a differential analysis of the exergy (Equation (25)) under the conditions (h_1, s_1) and the *W* constants results in:

$$dF = dI = T_0 \, dS_g. \tag{41}$$

Therefore, the following expression is obtained:

$$dF = T_0 \, dS_g = \frac{T_0}{T_d} \, dW_r. \tag{42}$$

Another important antecedent was the work of Alefeld [13], who worked on heat pumps and refrigeration systems: He questioned the use of the reference ambient temperature T_0 instead of a variable temperature T_x associated with the whole system. In particular, he proposed the case of a Rankine cycle, where this temperature T_x is equal to that of the condenser vacuum, T_{vac} . Alefeld was highly criticized by the community of exergy practitioners because the holistic vision that exergy provides was lost in his proposal. This article is a recognition of his work because mathematical proofs are stronger than reasonable assumptions.

The relative free energy function, ℓ , represents the local free energy conditioned by the deterioration path, *r*. It is an intensive property, and its corresponding extensive property,

$$\mathcal{L} = m\,\ell,\tag{43}$$

is the amount of energy of the exiting stream in a fuel of the type $E_1 - E_2$, which is not affected by the deterioration of the component. This is because when the exit flow changes its state owing to the deterioration, h and s vary by following the path $h_r = h_r(s_r)$. Consequently, the following expression is obtained:

$$d\ell_2 = dh_r - \left(\frac{dh}{ds}\right)_r ds_r = 0 \quad \text{or} \quad \ell_2 = \text{const.}$$
 (44)

In addition, the function $h_r = h_r(s_r)$ is neither a straight curve nor a slope T_0 . Therefore, ℓ exceptionally coincides with the specific exergy of the stream, and the exergy increase in the output stream in the turbine is: $ex_{2'} - ex_2 = (h_{2'} - h_2) - T_0(s_{2'} - s_2)$.

In the example of the turbine, (h_1, s_1) and W are constant; then, applying differential analysis to the unit exergy consumption definition, $k \equiv F/P$, it follows that:

$$dF = P \, dk. \tag{45}$$

Combining both Equations (41) and (45):

$$dk = \frac{T_0 \, dS_g}{W} = \frac{T_0}{T_d} \cdot \frac{T_d \, dS_g}{W},\tag{46}$$

and applying Equation (38), it follows that:

$$\left(\frac{dk}{dm}\right)_r = \frac{T_0}{T_d} \cdot \frac{\ell_1 - \ell_2}{W}.$$
(47)

This expression is quite important because it relates the loss of exergy efficiency in the turbine with the additional mass of fuel to compensate it at constant production. In other words, it relates the malfunction of the turbine with the need for more entering fuel. In addition, this expression opens the way of changing the paradigm of exergy by relative free energy.

Therefore, a new definition of the efficiency (or its inverse, specific consumption) of the turbine appears:

$$k_L = \frac{F_L}{P_L} = \frac{\mathcal{L}_1 - \mathcal{L}_2}{W} = \frac{H_1 - H_2 - T_d \left(S_1 - S_2\right)}{W}.$$
(48)

This new definition of efficiency of the turbine has the important property that if the turbine malfunction follows an *r* path, its characteristic equation becomes:

$$\mathcal{L}_1 = \mathcal{L}_2 + k_L W + \text{const.}$$
⁽⁴⁹⁾

This constant might be selected as the standard reference state for h and s calculations (h_0, s_0) . When a malfunction in the turbine follows a trajectory r with the W constant, it follows that:

$$\ell_1 dm = \ell_2 dm + W dk_L, \tag{50}$$

because $\ell_1 - \ell_2$ is constant along trajectory *r*. Therefore:

$$\frac{dk_L}{k_L} = \frac{dm}{m}.$$
(51)

In other words, any additional percentage of malfunction following a trajectory *r* with the *W* constant results in an additional percentage of mass of fuel entering the turbine.

In addition, note that exergy does not fulfill Equation (51) because:

$$ex_1 dm = ex_2 dm + m dex_2 + W dk \qquad dex_2 \neq 0.$$

Equation (49) is not a mere efficiency definition, as it is the unit exergy consumption definition $k \equiv F/P$. It corresponds to a physical description of the turbine system, and, more importantly, it does not depend on the reference environment temperature T_0 , but on the behavior of the turbine. The structural theory, as explained in this paper, together with the relative free energy function, allows the obtaining of an interesting characteristic function of the behavior of thermodynamic systems. If under the structural theory, the coefficients k_{ij} are the precursors of costs k_j^* , should these costs be their "natural" costs? Should they perhaps be named "regular" costs? In any case, these costs are directly related to the additional amount of resources needed to compensate the malfunction.

Equation (38) shows that the second law has not yet said the last word regarding the relationship between the thermodynamic quantity, quality, cost, and irreversibility. In general, the reason for why

 T_d is used instead of T_0 stems from the fact that the additional degraded energy not used in producing the product becomes part of the exiting stream instead of going directly to the environment at T_0 . The value of T_d depends on how great the additional irreversibility is. Such interpretation of T_d allows us to understand that its lowest attainable value is T_0 , while, apparently, it has no upper limit.

In other words, the deterioration lowers the free energy of the exiting stream. As this deterioration always relates to some component, this is why we name this function relative free energy. In the same way that the Gibbs free energy relates to some chemical reaction, the RFE relates to some component's deterioration in a system.

The key problem of diagnosis of energy systems stems in how to assess, as precisely as possible, the relationship between local irreversibilities and additional consumption of resources. At constant production, a local irreversibility needs additional resources to compensate it, but also modifies the exiting streams, affecting downstream enthalpies and entropies as well as, eventually, the upstream ones, if recycling. A certainty derives from the second law: Any inefficiency in a process increases the entropy generation. This means that any mechanical, thermal, or chemical loss generates entropy and reduces efficiency. However, any efficiency decrease means more resources (at equal quality) to get the same product. If one knows the amount of local resources needed to compensate a local deterioration, r, i.e.,

$$\left(\frac{\partial m_{local}}{\partial S_g}\right)_r$$

and knows how the global system's resources is related with local resources, i.e.,

$$\left(\frac{\partial m_{global}}{\partial m_{local}}\right)_r,$$

one may have a new theory of energy system diagnosis. We will present this theory with due examples in a following paper; however, an early analysis was published in [33].

9. Conclusions

The definition of efficiency plays a fundamental role in the process of calculating average exergy costs. So, efficiency and cost became closely linked. In such a way, the Theory of Exergy Cost [2,3] was extensively used to assess costs in many thermoeconomic/thermodynamic applications. However, the exergy cost depends on the plant disaggregation scheme. It is necessary to look after the cost formation process by searching for how much exergy has been consumed in the processes and where they have consumed it. The result of this activity is a given productive structure. However, if exergy depends on a chosen reference state, exergy efficiencies and their closely related costs will depend on this selection. Notwithstanding, any deterioration that increases entropy generation results in an additional expense of resources used to produce the same product. Both the entropy increase and the additional resources are measurable and free from analyst selections. Therefore, something fails in the conventional theory.

The use of exergy instead of enthalpy or the Gibbs function for obtaining costs increases the overall, coherent, and systematic view of a set of stream costs in a productive structure. To what extent could one use these costs to assess component malfunctions? In other words, can average costs be used as marginal costs?

The exergy cost is the exergy backpack, embodied exergy, or the exergy footprint of a commodity; in fact, Szargut named it the "cumulative exergy consumption" [16], i.e., its "past" characterization (history), while exergy is the potential energy of such a commodity, or its remaining capacity for doing something else. Can average costs predict future degradations or only past irreversibilities?

The purpose of thermoeconomics is to obtain a coherent and significant set of costs in a given structure. That is because its applications are directed towards the optimization and diagnosis of productive structures. Therefore, the costs of internal streams are quite important in analyzing the behavior of the system. Consequently, internal costs ought to be as sensitive as possible to system degradation. A theory that would provide exact costs would be the objective of thermoeconomic diagnosis. In fact, one can obtain the costs of final products or commodities without performing very detailed analyses. In other words, in no way is thermoeconomics, as it is already known, far from being finished. Moreover, analysts need to look for the cost formation process of wastes [18], which was not mentioned here even when some ideas developed here could be used to clarify it.

This paper presents a general theory of (linear) cost, demonstrating and answering questions like:

- To what extent, according to the linear characteristic equation (Equation (2)), can a component can be conformed to its efficiency definition, *F k P* = 0 ?
 In fact, exergy efficiency must be coherent with the component's design purpose, but one designs machines by observing the behavior of nature. So what is first, efficiency or nature? We overcome this drawback with Equation (48).
- Why the Rules *F* and *P*, or any other cost proposal, might be either rational or not under a given disaggregation scheme.
- Under a set of conditions, we may say that the exergy cost balances are the mathematical dual of exergy balances and vice versa. The exergy cost and the exergy are like specular images of the same entity.
- A compact vision of present-day thermoeconomics/exergoeconomics under Equations (20)–(23).
- A cost theory applicable to any thermodynamic function like, enthalpy, exergy, Gibbs free energy, or any other.
- In analyzing this last point, we proposed a new thermodynamic function called the relative free energy, ℓ , and introduced a new parameter T_d called deterioration temperature, which is due to a component's deterioration cause r and is characterized by a thermodynamic trajectory h = h(s, r) describing the effects on the exiting stream.
- The Legendre transform of the deterioration path, $h_2 = h_2(s_2, r)$, is the relationship $\ell_2 = \ell_2(T_{d,2}, r)$. In other words, the pairs ℓ_r and $T_{d,r}$ are inseparable in a deterioration path, r, as are the pairs (h_r, s_r) .
- The general formula (38) applies for different flowing streams in energy systems under each particular deterioration path, *r_i*. A given component may have several deterioration paths, not only one. Therefore, the concept of component malfunction needs be associated with that of deterioration paths. Besides that, this formula can be applied to any system—under the defined conditions—no matter its aggregation level. Each degradation will have its deterioration temperature as well as its corresponding RFE efficiency.
- A way for assessing appropriate characteristic equations of thermal systems was obtained here for the case of turbines.
- As the component's deterioration does not depend on the analyst's decision on the chosen reference state, the deterioration temperature no longer depends on the chosen reference temperature, nor does the new definition of efficiency using the RFE. This fact does not isolate the plant from environmental conditions, but eliminates the arbitrary selection of any reference state. That idea clarifies the role of the environmental conditions in the plant.

The Exergy Cost Theory provides reasonable costs. Will relative free energy provide a set of natural (or perhaps named regular) costs? In fact, the cost of a deterioration is directly related to the physical behavior of that deterioration. This way, this also means that these costs are, in fact, marginal costs, since they incorporate the future malfunction behavior of the component.

The theory sketched here opens new fields of knowledge, since new questions appear: Is exergy the best thermodynamic function when diagnosing systems? Why does T_0 need to be the same for each component of a given structure? Can we use this theory to assess objective average costs of deteriorations free from assumptions? The deterioration behavior of an energy system relates with internal marginal costs while exergy costs relate with history. Should we change our definitions of efficiency in light of the relative free energy function? Even if described early in the 1990s, all these

ideas are tools for the future [34]. Cost is a measure of expended resources to produce something; then, cost with the relative free energy instead of exergy would open a new field of a more precise theory of thermoeconomics. We are presently working with such ideas.

Author Contributions: Ideas, formulation of overarching research goals and aims, creation of models, writing of the initial draft, A.V.; verification of the overall reproducibility of results, C.T.; preparation of the published work—specifically, data presentation, C.T. All authors have read and agreed to the published version of the manuscript.

Funding: This research received no external funding.

Acknowledgments: Our special thanks to Dr Jean-Noël Jaubert who invited A. Valero to give a lecture at the Journées de exergie, Nancy, 22–23 November 2018, and Prof. Michel Feidt, who invited us to write the paper. They challenged us to explain and update this general theory of relative free energy, which has a great explanatory power, but was sleeping for a number of years.

Conflicts of Interest: The authors declare no conflict of interest.

References

- 1. Tsatsaronis, G.; Winhold, M. Exergoeconomic analysis and evaluation of energy-conversion plants-I. A new general methodology. *Energy* **1985**, *10*, 69–80.
- Valero, A.; Lozano, M.; Muñoz, M. A general theory of exergy saving. I. On the exergetic cost. In *Computer-Aided Engineering and Energy Systems: Second Law Analysis and Modelling*; ASME: New York, NY, USA, 1986; Volume 3, pp. 1–8.
- 3. Lozano, M.A.; Valero, A. Theory of the Exergy Cost. Energy 1993, 18, 939–960.
- 4. Martinez-Alier, J.; Schlupmann, K. *Ecological Economics: Energy Environment and Society*; Basil Blackwell Ltd.: Oxford, UK, 1987.
- 5. Georgecu-Roegen, V. *The Entropy Law and the Economic Process*; Harvard University Press: Cambridge, MA, USA, 1971.
- Sciubba, E.; Wall,G. A brief commented history of exergy from the beginnings to 2004. *Int. J. Thermodyn.* 2007, 10, 1–26.
- 7. Tribus, M.; Evans, E. *A Contribution to the Theory of Thermoeconomics*; Technical Report 62; University of California: Los Angeles, CA, USA, 1962.
- 8. El-Sayed, Y.M.; Evans, R.B. Thermoeconomics and Design of Heat Systems. *J. Eng. Power* **1970**, *92*, 27–35, doi:10.1115/1.3445296.
- 9. Valero, A.; Correas, L.; Lazzaretto, A.; Rangel, V.; Reini, M.; Taccani, R.; Toffolo, A.; Verda, V.; Zaleta, A. Thermoeconomic Philosophy Applied to Operating Analysis and Diagnosis of Energy Utilty Systems. *Int. J. Thermodyn.* **2004**, *7*, 33–39.
- 10. Valero, A. The duality between exergy efficiencies and exergy costs. The structural theory and the relative free energy function. In Proceedings of the Journées sur le Thème de L'éxergie, Nancy, France, 22–23 November 2018.
- Valero, A.; Lozano, M. General theory of thermoeconomics: Part II. The relative free energy function. In Proceedings of the ECOS '92 International Symposium, Zaragoza, Spain, 15–18 June 1992; pp. 147–154.
- 12. Baehr, H.D. Thermodynamik; Springer: Berlin/Heidelberg, Germany, 2005.
- 13. Alefeld, G. Problems with the exergy concept (or the missing Second Law). *IEA Heat Pump Newsl.* **1988**, 6, 19–23.
- 14. Valero, A.; Torres, C.; Serra, L. General theory of thermoeconomics: Part I. Structural analysis. In Proceedings of the ECOS '92 International Symposium, Zaragoza, Spain, 15–18 June 1992; pp. 137–145.
- 15. Morris, D.R.; Szargut, J. Standard Chemical Exergy of Some Elements and Compounds on the Earth Planet. *Energy* **1986**, *11*, 733–755.
- 16. Szargut, J.; Morris, D.R.; Steward, F. *Exergy analysis of Thermal, Chemical, and Metallurgical Processes*; Hemisphere: New York, NY, USA, 1988.
- 17. Tsatsaronis, G. Definitions and nomenclature in exergy analysis and exergoeconomics. *Energy* **2007**, 32, 249–253, doi:10.1016/j.energy.2006.07.002.
- 18. Torres, C.; Valero, A.; Rangel, V.; Zaleta, A. On the cost formation process of the residues. *Energy* **2008**, 33, 144–152.

- 19. Bejan, A.; Tsatsaronis, G.; Moran, M.J. *Thermal Design and Optimization*; John Wiley & Sons: New York, NY, USA, 1996.
- 20. Leontief, W. Environmental Repercussions and the Economic Structure: An Input–Output Approach. *Rev. Econ. Stat.* **1970**, *52*, 262–271.
- 21. Boyd, S.; Vandenberghe, L. Convex Optimization; Cambridge University Press: Cambridge, UK, 2004.
- 22. Valero, A.; Carreras, A.; Torres, C.; Lozano, M.A. On Causality in Organized Energy Systems (parts I, II and III). In *A Future for Energy*; Pergamon Press: Oxford, UK, 1990; pp. 387–420.
- Valero, A.; Serra, L.; Lozano, M.; Advanced Energy Systems Division; ASME Heat Transfer Division. Structural theory of thermoeconomics. In *Thermodynamics and the Design, Analysis and Improvement of Energy Systems*; H00874; Richter, H.J., Ed.; The American Society of Mechanical Energineers: New York, NY, USA, 1993; Volume 30, pp. 189–198.
- 24. Odum, H. Self-organization, transformity, and information. Science 1988, 242, 1132–1139, doi:10.1126/science.242.4882.1132.
- 25. Brown, M.; Herendeen, R. Embodied energy analysis and EMERGY analysis: A comparative view. *Ecol. Econ.* **1996**, *19*, 219–235, doi:10.1016/S0921-8009(96)00046-8.
- 26. Royo, J. Las Ecuaciones Caracteristicas de los Sistemas Térmicos. La Energía Libre Relativa. Ph.D. Thesis, Universidad de Zaragoza, Zaragoza, Spain, 1994.
- 27. Royo, J.; Valero, A. Towards a unified description of the energy behavior of thermomechanical systems. In *Thermodynamics and the Design, Analisys and Improvement of Energy Systems;* Krane, R.J., Ed.; ASME: New York, NY, USA, 1995; Volume 35, pp. 127–134.
- 28. Valero, A.; Correas, L.; Zaleta, A.; Lazzaretto, A.; Verda, V.; Reini, M.; Rangel, V. On the thermoeconomic approach to the diagnosis of energy system malfunctions Part 2. Malfunction definitions and assessment. *Energy* **2004**, *29*, 1889–1907.
- 29. Valero, A.; Torres, C.; Lerch, F. Structural Theory and Thermoeconomic Diagnosis. Part III: Intrinsic and Induced Malfunctions. In Proceedings of the ECOS'99, Tokyo, Japan, 8–10 June 1999.
- Torres, C.; Valero, A.; Serra, A.; Royo, J. Structural Theory and Thermoeconomic Diagnosis. Part I: On Malfunction and Dysfunction Analysis. In Proceedings of the ECOS'99, Tokyo, Japan, 8–10 June 1999; pp. 368–373.
- 31. Callen, H.B. Thermodynamics and an Introduction to Thermostatistics, 2nd ed.; Wiley: Hoboken, NJ, USA, 1985.
- 32. Alberty, R. Use of legendre transforms in chemical thermodynamics: (IUPAC Technical Report). *Pure Appl. Chem.* **2001**, *73*, 1349–1380, doi:10.1351/pac200173081349.
- 33. Royo, J.; Valero, A.; Zaleta, A. The dissipation temperature: A tool for the analysis of malfunctions in thermomechanical systems. *Energy Convers. Manag.* **1997**, *38*, 1557–1566.
- 34. Valero, A. El marco termodínamico para iluminar la sociedad actual. In *Economía, Ecología y Sostenibilidad en la Sociedad Actual;* Naredo, J.M., Parra, F., Eds.; Siglo XXI de España Editores: Madrid, Spain, 2000; pp. 69–75.



© 2020 by the authors. Licensee MDPI, Basel, Switzerland. This article is an open access article distributed under the terms and conditions of the Creative Commons Attribution (CC BY) license (http://creativecommons.org/licenses/by/4.0/).