



Article

Isolation Properties of Low-Profile Magnetorheological Fluid Mounts

Mehdi Ahmadian 1,* and Brian M. Southern 2

- Center for Vehicle Systems & Safety, Virginia Tech, MC-0901, 3103 Commerce Street, Blacksburg, VA 24061, USA
- Volvo Group, 7900 National Service Road, Greensboro, NC 27409, USA; brian.southern@volvo.com
- * Correspondence: ahmadian@vt.edu

Abstract: This study evaluates the stiffness and damping characteristics of low-profile magnetorheological (MR) fluid mounts (MRFM) to provide a better understanding of the vibration improvements offered by such mounts, as compared with conventional elastomeric mounts. It also aims at assessing how much of the mount's performance is due to the MR fluid and how much is due to the elastomer and steel insert that is used in MRFM. The study includes the design, analysis, fabrication, and testing of a unique class of MRFM that is suitable for the isolation of sensitive machinery and sensors. The MR fluid is compressed (squeezed) in response to dynamic force applied to the mount. The test results are compared with conventional elastomeric (rubber) mounts of the same configuration as MRFM, to highlight the changes in stiffness and damping characteristics for frequencies ranging from 1 to 35 Hz. With no current supplied, the MRFM has a slightly higher stiffness and nearly the same damping as a conventional rubber mount. The slight increase in MRFM stiffness is attributed to the MR fluid's compressive stiffness, which is higher than the rubber. When current is supplied to the MRFM, the stiffness and damping increase significantly at lower frequencies and taper off to nearly the same level as the rubber mount at higher frequencies. Both the stiffness and damping are directly proportional to the supplied current. At the maximum current of 2 A, the MRFM has 200% higher stiffness and 700% higher damping than the rubber mount. The significantly higher damping and stiffness and the tapering off to nearly the same level as the rubber mount is quite interesting and intriguing. It indicates that MRFM delivers high damping and stiffness when needed, while significantly tapering them off when high damping and stiffness are not desirable.

Keywords: magnetorheological; fluid mount; MRFM; low profile; vibration isolation; elastomeric mount



Citation: Ahmadian, M.; Southern, B.M. Isolation Properties of Low-Profile Magnetorheological Fluid Mounts. *Fluids* **2021**, *6*, 164. https://doi.org/10.3390/fluids6040164

Academic Editors: Ioannis Sarris and Mehrdad Massoudi

Received: 12 March 2021 Accepted: 13 April 2021 Published: 19 April 2021

Publisher's Note: MDPI stays neutral with regard to jurisdictional claims in published maps and institutional affiliations.



Copyright: © 2021 by the authors. Licensee MDPI, Basel, Switzerland. This article is an open access article distributed under the terms and conditions of the Creative Commons Attribution (CC BY) license (https://creativecommons.org/licenses/by/4.0/).

1. Introduction

Discovered by Jacob Rabinow in 1948, magnetorheological (MR) fluids belong to a class of fluids that exhibit variable yield stress, commonly known as non-Newtonian fluids [1]. Consisting of micron-sized ferrous (Fe) particles suspended in a carrier fluid, they have the ability to change from a fluid state to a semi-solid or plastic state rapidly upon the application of a magnetic field. The degree of change is related to the magnetic field strength and may occur in a matter of a millisecond(s) [2,3]. In their semi-solid state, they exhibit field-dependent viscoplastic behavior that is characterized by field-dependent yield stress. This feature along with the fluid's fast response time has made MR fluids an attractive technology for many applications [4].

The fluid is commonly used in one of three modes that are shown in Figure 1. The valve mode is commonly used in damping devices that use MR fluids, such as vehicle suspensions [5–11]. The valve mode uses the fluid flow between fixed parallel plates. The shear mode is most often used in real-time-adjustable devices such as MR brakes and clutches. The squeeze mode is far less common than the other two modes. In a limited number of studies, it has been considered for mitigating vibrations with small amplitudes [12,13]. In squeeze mode, it is often assumed that the lateral flow of the fluid

Fluids 2021, 6, 164 2 of 16

has Poiseuille-like behavior, which is common to the shear mode application of the fluid. The MR mounts described in this study use the MR fluid within a conventional low-profile elastomeric (rubber) mount. Such a device can potentially be used for adjustable (and adaptable) vibration isolation of highly sensitive electronics and machinery, sensory systems with precise measurement requirements, and other similar applications. As will be described later, the MR fluid provides stiffness and damping characteristics that are far superior to what can be achieved by a conventional rubber mount.




Figure 1. Magnetorheological (MR) fluid modes: (a) valve mode; (b) shear mode; (c) squeeze mode.

Conventional hydraulic mounts (also called fluidlastic mounts) with MR fluids have been studied in many past studies, mainly for engine vibration isolation [14]. The forces transmitted by the engine are reduced due to the mount's compliance and the damping created by the fluid passage through an inertia track, which in some designs also creates a tuned vibration absorber effect. The fluid used in conventional hydraulic mounts is a medium viscosity oil, not too dissimilar to automobile engine oil. Several studies have extended the design and analysis of conventional hydraulic mounts to mounts that use MR fluids [15–17]. Among other researchers, Koo et al. have investigated control policies for tuned vibration absorbers, which could be used to control MR fluid mounts [18].

Other applications of MR material include magnetorheological elastomers, which are a composite of rubber and embedded magnetic particles. The magnetic particles are suspended in the elastomer and are aligned with an applied magnetic field while the elastomer is cured. This applied field causes the microstructures of the iron particles to form chains during the curing, as described by Boczkowska [19].

Low-profile rubber mounts with an MR-filled interior cavity have also been studied by Wang et al. [20]. Their study showed that including the MR fluid within the mount increases output force transmission through the mount by a maximum of 75%, for an oscillatory input [21]. In another study of similar mounts, York et al. showed such mounts to have tunable damping and dynamic stiffness [22]. As compared with the study by Wang, York's design includes an internal steel plate to alter the magnetic circuit to place the poles of the electromagnet directly above and below the fluid chamber for improved magnetic efficiency. This design uses a large magnetic field generator, which may be difficult to package. These designs are included in a U.S. patent issued in 2005 [23].

What the study by Wang and York, and others similar to them do not make clear is how much of the added stiffness is due to including MR fluid, steel plate(s), or other elements that are far stiffer than the rubber. They also do not make it clear how much of the stiffness contributions are due to the change in the mount's geometry (the inclusion of a cavity within the mount). Additionally, they do not evaluate the change in damping properties of the mount, as compared with a conventional rubber mount, or the extent of damping variation that can be achieved for the range of electrical current that the mount is designed for, most commonly 0–2 A.

Other related studies suffer from the same shortcomings. For instance, the studies in [24–26]. In [24], Hua et al. provide a review of the magnetorheological devices, as studied in the open literature from 2018 to 2020. Some of the devices that are studied are magnetorheological brakes, clutches, dampers, and mounts. The authors conclude that there have been vast advances in the development of magnetorheological proposed in the

Fluids 2021, 6, 164 3 of 16

recent years, although there remain challenges in studying some of the characteristics of the MR devices in shear-squeeze mode, such as the type of the mounts that are studied in this paper.

Kavlicoglu, B. et al. introduced a magnetorheological mount that can reduce or increase its stiffness based on payload and shock and vibration input [25]. The paper describes the details of the fabrication and testing of the proposed mount, which is fundamentally different from the low-profile MRFM that is discussed here. Additionally, the study in [25] does not provide any assessment of the differences between the MR mount and similarly configured elastomeric mounts. Specifically, it does not make it clear how much of the mount's performance is due to the MR fluid and what aspects of the laboratory results are due to the elastomeric construction of the mount.

Jalali et al. described the design, fabrication, and testing of a bi-directional shear mode magnetorheological mount [26]. The mount is designed so that the movements in both vertical and transverse directions can be accommodated by the shear mode of the MR fluid. How the MR fluid is used in this design, as well as its intended practical applications, are entirely different from our study. Additionally, similar to other papers, this study does not make clear the differences between the proposed MR mount and a similarly configured fluidlastic mount. It does not evaluate the performance improvements and benefits due the MR fluid. This study aims at providing a more in-depth evaluation of the stiffness and damping characteristics of the rubber mounts with embedded MR fluid, referred to as MR fluid mount (MRFM). The evaluation is intended to shed a light on how MRFM performs in various frequencies that are expected to be encountered in isolating sensitive machinery and equipment. Additionally, an in-depth comparison is performed with conventional rubber mounts of the same geometry to differentiate between the contributions of the rubber component and MR fluid.

After describing the MRFM configuration, the paper provides some of the design analysis that is performed in fabricating a series of prototype mounts for the study. Next, it provides the test setup and an analysis of the test results.

2. MR Fluid Mount (MRFM) Configuration

Figure 2 includes an isometric view of the MR fluid mounts (MRFM) that are considered for this study. The major design components are the metal-elastic case mount and the magnetic circuit's upper and lower housing. The lower housing contains a magnetic core with a concentric coil bobbin that is locked in place by a spacer. The spacer provides a flush surface for the mount. A detailed diagram of the MRFM is shown in Figure 3. Resembling a flat disk, the mount includes a fluid cavity and two metal end caps that are used to close the magnetic circuit through the MR fluid-filled cavity. Although this study addresses a design with the specific dimensions summarized in Table 1, the results are not confined to a specific mount with those dimensions. The findings of the study are appliable to other mounts with different dimensions, although the magnitude of forces and displacements are scaled according to the size of the mount. More details on the design of the mount and magnetic system are included in [27].

Fluids 2021, 6, 164 4 of 16




Figure 2. Isometric view of the MR fluid mount (MRFM) and magnetic circuit design.




Figure 3. (a) Elastic casing sectional view, (b) elastic casing with magnetic-pole plate inserts sectional view, and (c) isometric view of MR fluid mount (MRFM) casing.

Table 1	Dimensions and	l material proper	ties of the electron	nagnetic components ar	nd nackaging and	l testing dimensions
Table 1.	. Dimensions and	i matemai brober	des of the electron	nagneuc connochents at	iu Dackaying and	i testing annensions.

Modeled Component	Outside Diameter in.	Inside Diameter in.	Component Height in.	Material Permeability <i>B-H</i>
Top-Assembly				
Upper Housing	3.000	N/A	0.250	1018 Steel
Upper-Pole Plate	2.375	N/A	0.125	1018 Steel
Elastomeric Casing	2.375	1.625	0.3125	Air
Magnetic-Pole Plate	1.625	N/A	0.125	1018 Steel
Fluid Cavity	1.625	N/A	0.1875	MRF-140CG
Spacer	2.500	1.350	0.250	6061 Alu
Bottom-Assembly				
Lower Housing Base	3.750	2.400	1.800	1018 Steel
Extruded Lower Housing	3.750	3.125	0.8125	1018 Steel
Magnetic Core	1.460	N/A	1.300	1018 Steel
800 Turn Electro Coil	2.375	1.460	1.048	24 AWG
Cosmos Coil-Bobbin 0680	2.375	1.460	1.048	N/A
Total-Assembly				
Package Dimensions	3.75	N/A	2.613	
Testing Setup	3.75	N/A	4.613	

The normal forces compress the mount and squeeze the MR fluid. The change of the magnetic field strength through the mount is intended to change the dynamic characteristics of the fluid in the squeeze mode, hence influencing the isolation characteristics of the MR mount in real-time. The key question that is before us is how exactly and to what extent the mount's isolation properties change in response to the changes in the magnetic field. Although such studies are available for other types of MR devices, most prominently dampers in which the fluid is used in the valve mode, they are scant for the squeeze-mode devices such as the mount in Figures 2 and 3.

Fluids 2021, 6, 164 5 of 16

3. MR Fluid Mount (MRFM) Analysis, Design, and Fabrication

A model of the electromagnetic circuit for the test prototype shown in Figures 2 and 3 is developed using Finite Element Methods Magnetics (FEMM). FEMM analyzes the axis-symmetric vertical cross-section of a magnetic circuit. The model allows evaluating the contours of the magnetic flux density |B| as well as the magnetic field intensity |H|, for the mount's dimensions, material properties, coil windings, and wire gauge at a given supplied current. The B-H curves for the four different MR fluid (MRF-122, 132, 140, and 145) that are considered for the study are modeled according to

$$B = 1.91 \cdot \Phi^{1.133} \cdot [1 - \exp(-10.97 \cdot \mu_0 \cdot H)] + \mu_0 \cdot H, \tag{1}$$

where B is the magnetic flux (Tesla or kAmp/m), H is the magnetic field intensity (Amp/m), Φ is the percentage of ferrous iron in the fluid (unitless), and the constant $\mu_0 = 4\pi 10^{-7}$ [28]. The numbering designation for each fluid indicates the percentage of ferrous iron in the fluid by volume. For instance, MRF-122 has 22% volumetric ferrous iron, and Φ is set to 0.22 for the fluid. Changing the magnetic field intensity H from 0 to 600 kAmp/m in Equation (1), we can determine the magnetic flux B and use it in the FEMM model to determine flux density within the electromagnetic circuit, as shown in Figure 4. The FEMM analysis is mainly used to highlight any bottleneck that may exist in the magnetic circuit and change the geometry to achieve a more uniform flux density or flux flow through the circuit.




Figure 4. Simulated (a) flux density and (b) magnetic flux magnitude for MRF-122 with 3 As of supplied current.

For brevity, Figure 4 is used as a sample for the extensive FEMM analysis that was performed for the study. The complete analysis is available in [27]. The same document also includes the details of the rubber selection, model design, and fabrication of various mounts that are shown in Figure 5.




Figure 5. MR fluid mount (MRFM) mounts with 6061 aluminum, air, 1018 steel, and solid 30 Durometer polyurethane (rubber).

Fluids **2021**, 6, 164 6 of 16

The dimensions for each mount are documented in Table 2. Additionally, the designation abbreviations used for each mount are included in Table 3. The mount designations in Table 3 and Figure 5 are according to the inserts, or lack thereof, for each mount. Two of the mounts have metal inserts, one 6061 aluminum, and another 1018 steel insert. The other two mounts shown in the figure have no metal inserts. One is built with an air cavity where the metal insert is normally placed and the other one is simply made of rubber with no metal inserts or air cavity. The choice of the mounts is so that the stiffness and damping characteristics of the MRFM can be related to different aspects of the mount. For instance, differentiating between the MRFM with aluminum (non-ferrous) and steel insert allows us to evaluate the contributions due to the changes in MR fluid yield stress, as the former allows the magnetic flux to flow through the fluid and the latter does not. The comparison with the air mount and rubber mount allows determining how much of the mount's performance is due to the compression properties of the fluid. The rubber mount also allows assessing how much of the stiffness and damping of the MRFM is due to the rubber material itself.

Table 2. Polyurethane metal-elastic and elastic casing dimensions with internal cavity dimensions for the specified insert.

P.U. Casing with Type of Insert	Mount Height Inch	Mount Diameter Inch	Insert Height Inch	Insert Diameter Inch
MRF-145	0.4375	2.375	0.1875	1.625
Air	0.4375	2.375	0.1875	1.625
30 D Polyurethane	0.4375	2.375	0.1875	1.625
1018 Steel 6061 Aluminum	0.4375 0.4375	2.375 2.375	0.1875 0.1875	1.625 1.625

Table 3. Mount naming nomenclature for abbreviations and legends.

Name	Type of Insert		
MRE	MRF-145		
AIR	Air		
RUB	30-D Polyurethane		
STE	1018 Steel		
ALU	6061 Aluminum		

4. MRFM Test Setup

The mounts were tested in a suspension dynamometer, shown in Figure 6. The crossbar is used to preload the mount to approximately 100 N in order to reflect the static load that would be placed on it in practice. Due to the variations in the stiffness of the mounts that are tested (Figure 5), the static load causes different static displacements, which is included in the analysis of the test results. The mounts are run through a warm-up period of approximately one minute before data collection. Unfortunately, a temperature reading was not possible due to the lower housing blocking the infrared temperature sensor. Therefore, the warm-up was done by running a sine-sweep test at a current setting of 2.0 A at a defined slow rate for a specific length of time. The warm-up was used in both the quasi-static and dynamic testing formats for the three MRFM filled with MRF-145 (MRE 1-3), one empty metal-elastic mount (MRE 3B), one empty elastic mount (AIR), one solid elastic (RUB), one elastic case mount with steel insert (STE), and one elastic case mount with aluminum insert (ALU). The MRE 3B and AIR are nearly the same, in the sense that for both the fluid cavity is not filled with MR fluid. The MRE 3B, however, has a metal insert (12L14 steel, the same as for all of the MR mounts), whereas AIR does not have a metal insert.

Fluids **2021**, *6*, 164 7 of 16




Figure 6. MR fluid mount (MRFM) test setup in a suspension dynamometer.

For the quasi-static tests, a ramp input from 0 to 1 mm over 3 s is used for the softcore mounts, and a ramp input from 0 to 0.5 mm over 3 s is used for the solid core mounts in Figure 7a. The sinusoidal displacement in Figure 7b is used for the dynamic tests, with the amplitude and frequencies shown in Table 4. The tables show the electrical current variation for each type of mount, along with the amplitude and frequency that was used for each displacement input. The test conditions were adjusted according to the normal stiffness of the mounts to ensure that the resulting forces remain within the limits of the dynamometer load cell (2000 lb). For instance, the mounts with solid cores, which are denoted with an asterisk, were tested at 0.25 in amplitude since 0.5 in result in forces that are larger than the loadcell's maximum force rating, 2000 lb or 9000 N.




Figure 7. Quasi-Displacement input used for MR fluid mount (MRFM) testing; (a) Static displacement; (b) Dynamic displacement.

Table 4. Test matrix for dynamic testing of MR mount.

Mount Insert	Frequency	Current	Amplitude
	Hz	A	mm
MRE 1-3 MRE 3B AIR RUB STE * ALU *	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 12, 14, 16, 18, 20, 25, 30, 35	0.00, 0.50, 1.00, 1.50, 2.00	0.5 0.5 0.5 0.5 0.25 *

^{*} denotes decreased test amplitude from 0.5 mm to 0.25 mm.

Fluids 2021, 6, 164 8 of 16

5. Test Results

To establish the stiffness for each of the mounts in Table 3, they were tested with the quasi-static ramp displacement in Figure 7a. The stiffness plot in Figure 8 shows a sample of the results for each mount. The initial displacement due to preloading the mount is discarded for the dynamic stiffness analysis because it simply represents the mount's response to the static load placed on it. The displacements beyond 0.2 mm are used for the dynamic analysis throughout the study. The test result indicates a linear stiffness within the dynamic range, with a slope of K, which can be established through a simple curve fit. The stiffness K of various mounts considered for the study are summarized in Table 5.




Figure 8. Stiffness characterization testing for the MR fluid mount (MRFM) with MRF-145.

Table 5. Summary of mount stiffness for various configurations tested with a quasi-static ramp
displacement input.

Mount	Static Stiffness, N/mm												
Supplied Current, A	0.00 0.25		0.50	0.75	0.75 1.00		1.50	1.75	2.00				
MRE 1	2587	2587	2846	3037	3236	3396	3543	3619	3688				
MRE 2	2905	2959	3041	3170	3288	3398	3481	3547	3603				
MRE 3	2292	2287	2257	2302	2370	2456	2547	2627	2674				
MRE 3B	575	585	579	572	566	558	550	541	533				
AIR. Est	460	460	460	460	460	460	460	460	460				
RUB	2037	2033	2034	2035	2036	2038	2039	2041	2043				
STE	4212	4206	4204	4204	4203	4202	4206	4210	4218				
ALUM	4280	4326	4352	4362	4374	4378	4397	4410	4421				

As expected, the two mounts without a metal insert or MR fluid have the smallest normal (vertical) stiffness, whereas the two with the metal inserts have the largest stiffness. The MRE 3B mount has a slightly higher stiffness than the AIR mount, but significantly lower than RUB, mainly because MRE 3B has an air pocket that causes a significant reduction in stiffness. The MRFM offers stiffness that is lower than the two mounts with metal inserts and the one mount with no insert. Unlike the other mounts that have no mechanism to respond to the supplied current, the MRFM's stiffness increases with increasing current, at a slightly different rate for each of the three mounts. The difference is due to slight variations in manufacturing the prototypes. The percent change in stiffness is 42%, 24%, and 17% for the MRFM, i.e., MRE 1, MRE 2, and MRE 3, respectively. It is also noted that the initial stiffness for each mount is slightly different. The differences are

Fluids 2021, 6, 164 9 of 16

attributed to slight changes in fabricating the prototypes in the lab. They could also be caused by any slight variations in the depth of epoxy primer substrate on the metal poles, which increases the magnetic impedance and reduces flux density within the MR fluid.

The response of the mounts to the sinusoidal dynamic displacements shown in Figure 7b is also measured to establish their dynamic characteristics. Unlike the quasi-static stiffness tests, the dynamic tests involve analyzing the force-displacement response within one or more cycles, as shown in Figure 9. The red dashed line is the mount force-displacement plot from the quasi-static tests and its slope represents the mount stiffness. The dynamic tests are performed at 0.0, 0.5, 1.0, 1.5, and 2.0 As for all mounts in Table 4. The sinusoidal displacement was swept from 1 to 35 Hz at a slow rate, to highlight the changes in mounts' stiffness and damping with frequency.




Figure 9. Dynamic testing of MR fluid mount (MRFM) with a sinusoidal displacement input over one cycle.

Similar to the stiffness tests, the initial displacement from the free height is ignored since it represents the deflection due to the static load on the mounts. The remainder of the cycle is used for the analysis. The test cycle includes the loading (compressing) and unloading (relieving) of the mount during the dynamic cycle. The results clearly show the significant hysteresis that is present in MRFM. The hysteresis is estimated to be caused by both the elastomer and the MR fluid. The equivalent damping coefficient of the mount can be calculated as

$$c_{eq} = \frac{\Delta E}{\pi \omega X^2},\tag{2}$$

where ΔE is the energy dissipated per cycle, ω is the input frequency in rad/s, and X is the displacement amplitude [28]. The energy dissipated per cycle, ΔE is calculated using the *polyarea.m* function in Matlab.

Figure 10 shows the dynamic test results for one of the MRFM at 1 Hz, with the supplied current varying from 0.0 to 2.0 A, in 0.5 A increments. The last plot shows the straight-line fit for each current.

Fluids **2021**, *6*, 164 10 of 16




Figure 10. Dynamic test results for MR mount at 0.0 to 2.0 A supplied current with a 1 mm sinusoidal input at 1 Hz.

The results show that, as expected, the mount stiffness increases with increasing current, as indicated by the slope of the straight line. Interestingly, the plots also indicate that the hysteresis loop grows in width with the increasing current. This means that increasing the supplied current not only increases the MRFM's stiffness, but also their damping.

The flux density, *B*, across the MR fluid is shown in Figure 11. Since it was not possible to measure the flux density during the tests, the figure shows the FEMM modeling results for various currents. There is a slight amount of warping of the magnetic field toward the edges, which often occurs due to the transition from a magnetic to non-magnetic medium. For the most part, the flux density is constant across the MR fluid. Additionally, the difference in flux density at 2 and 3 A, is far smaller than other currents, indicating that the fluid is approaching its magnetic saturation beyond 2 A. For the tests, the supplied current is capped at 2.0 A.




Figure 11. FEMM-simulated flux density radial distribution (at the magnetic-pole plate boundary).

Many tests are performed on the mounts listed in Table 4 and the complete results are documented in [27]. The results are used to determine the change in each mount's stiffness

Fluids **2021**, *6*, 164


and damping at various frequencies. They are also used to determine how much of the stiffness and damping that is measured during the tests are due to the MR fluid and how much is because of the elastomer and metal inserts. As noted earlier, to the best of our knowledge, no past study has explored this aspect of MRFM.

As shown in Figure 12a for one of the MR mounts, there is a significant increase in stiffness with the applied current. More notably, the increase in stiffness is steadily increasing with increasing current, which suggests that the magnetic circuit (including the MR fluid) has not reached saturation. The stiffness increases by 78% at 2 A relative to 0 A supplied current. Concurrently, the equivalent damping for the MR mount in Figure 12b also increases with the current, but on a larger scale than the stiffness magnitude. The increase in damping force is more than 500% for 2 A, relative to 0 A. The increase in damping, however, mainly occurs at low frequencies and it significantly tapers off with increasing frequencies. At the higher frequencies, there is not a significant increase in damping for various supplied currents. This is an exceedingly interesting and intriguing result, as in practice the mount is desired to have higher damping at lower frequencies to reduce any resonance peaks and have lower damping at higher frequencies to reduce vibration transmission (or improve isolation). The results indicate that the MR mount is able to deliver damping when needed and significantly taper it off when it is not desirable. The results in Figure 12 are summarized in Table 6.

Table 6. Stiffness and damping of the MR mount for various supplied currents at different frequencies.

MRE 1	F /X—Stiffness, N/mm																	
Current,								F	reque	ncy, Hz	Z							
	1	2	3	4	5	6	7	8	9	10	12	14	16	18	20	25	30	35
0.00	2806	2841	2888	2861	2864	2852	2838	2787	2734	2668	2683	2675	2667	2653	2653	2654	2639	2692
0.25	2947	2991	3038	3017	3017	3004	2962	2933	2898	2826	2810	2790	2789	2818	2762	2764	2749	2762
0.50	3257	3323	3374	3357	3327	3298	3295	3194	3168	3064	3057	3039	2997	3041	2974	3018	2982	2888
0.75	3681	3789	3846	3818	3792	3749	3701	3560	3550	3375	3357	3287	3297	3309	3243	3262	3247	3288
1.00	4192	4285	4331	4222	4186	4138	4079	3946	3864	3653	3653	3561	3582	3516	3481	3532	3499	3520
1.25	4676	4746	4795	4675	4644	4584	4466	4309	4220	3980	3973	3941	3851	3851	3772	3868	3751	3836
1.50	5121	5141	5054	5028	4997	4894	4833	4620	4515	4254	4239	4215	4077	4011	3973	4103	4068	3920
1.75	5501	5460	5385	5310	5282	5183	5061	4788	4802	4409	4421	4283	4255	4216	4322	4337	4180	4104
2.00	5852	5758	5667	5580	5483	5364	5253	5015	4879	4564	4528	4371	4316	4371	4242	4373	4242	4327
MRE 1								Da	mping	g, Ns/m	ım							
Current,								F	reque	ncy, Hz	z							
Α	1	2	3	4	5	6	7	8	9	10	12	14	16	18	20	25	30	35
0.00	26.2	10.9	6.2	4.2	3.0	2.2	1.5	1.2	0.9	0.70	0.43	0.06	0.00	0.11	0.30	0.56	0.70	0.84
0.25	41.4	18.1	11.0	7.6	5.6	4.4	3.4	2.7	2.3	1.93	1.38	0.95	0.82	0.11	0.30	0.30	0.76	0.52
0.50	67.3	29.2	18.4	13.0	9.8	7.9	6.4	5.3	4.6	3.91	3.06	2.30	1.96	1.57	1.26	0.12	0.23	0.03
0.75	92.7	39.8	25.3	18.4	13.8	11.3	9.1	7.5	6.6	5.70	4.44	3.58	3.04	2.55	2.03	1.25	0.23	0.41
1.00	116.3	48.4	30.8	22.5	16.6	13.4	10.9	9.1	8.0	6.85	5.52	4.38	3.78	3.08	2.55	1.75	1.11	0.41
1.25	132.9	54.5	34.5	25.5	18.9	15.5	12.4	10.6	9.3	7.86	6.23	5.10	4.40	3.60	3.04	2.08	1.37	0.86
1.50	148.2	59.9	38.1	28.0	20.8	16.7	13.8	11.6	10.0	8.63	6.89	5.67	4.80	3.95	3.38	2.28	1.53	0.94
1.75	155.3	62.4	39.4	28.7	21.6	17.5	14.4	12.1	10.6	9.05	7.24	5.98	5.11	4.22	3.56	2.54	1.69	1.09
2.00	162.8	63.4	38.7	27.5	20.2	16.4	13.5	11.4	9.8	8.29	6.73	5.49	4.66	4.01	3.30	2.23	1.41	0.93

Fluids **2021**, *6*, 164 12 of 16



(a)

(b)





Figure 12. MR fluid-elastic 1 mount (MRF-145) (**a**) stiffness |F|/X, and (**b**) damping C_{eq} at various frequencies.

Comparing the results in Figure 12 and Table 6 with similar results for the rubber mount (RUB) in Figure 4 provides the stiffness and damping changes due to the MR fluid. As shown in Figures 13 and 14, the MR mount with zero current (i.e., with no MR fluid effect) has slightly larger stiffness and nearly the same damping as the rubber mount. The slight increase in stiffness (Figure 13a) is due to the MR fluid having a larger normal stiffness than rubber when no current is passing through it. Figure 1a suggests that the MR fluid's damping is nearly the same as rubber at nearly all frequencies when no current is supplied to the fluid.

Fluids **2021**, *6*, 164 13 of 16






Figure 13. Comparing stiffness magnitude of a solid elastic case (RUB) to an MR fluid-elastic mount at **(a)** 0 As and **(b)** 2 As of current.

Fluids **2021**, *6*, 164 14 of 16




Figure 14. Comparing damping of a solid elastic case (RUB) to an MR fluid-elastic mount at (a) 0 As and (b) 2 As of current.

When the MR fluid is subjected to 2 A of supplied current, an entirely different picture emerges. For that condition, the MR mount offers far higher stiffness (Figure 13b) and damping (Figure 14b). The difference between the mount with no current and max current (2 A) is entirely due to the increase in the MR fluid's yield strength when it is squeezed as a result of a normal force applied to the mount. At its peak, stiffness has increased by nearly 200% and damping has increased by 700%. At higher frequencies, the gap between MRFM and rubber mount narrows, particularly for damping. As stated earlier, the MRFM's damping decreases significantly at higher frequencies. Figure 14b indicates that the MRFM's damping at higher frequencies is primarily due to the elastomer and not the MR fluid. It can be concluded that the MR fluid in squeeze mode offers little to no damping at higher excitation frequencies but provides plenty of damping at lower excitation frequencies.

Fluids 2021, 6, 164 15 of 16

As noted earlier, a more comprehensive treatment of the comparison between the MRFM and other mounts in Table 4 is included in [27], but not included here for brevity.

6. Conclusions

The study provides a critical evaluation of stiffness and damping characteristics of low-profile magnetorheological (MR) fluid mounts (MRFM) through an extensive series of laboratory tests, some of which are provided in the paper. The reader is encouraged to consult reference [27] for the complete study. Compared with earlier studies, the analysis offered in this paper provides an in-depth evaluation of the effect of MR fluid on the stiffness and damping of MRFM, which has not been studied in the past.

The design, analysis, fabrication, and testing of a unique class of MRFM that is suitable for the isolation of sensitive machinery and sensors is provided. The prototype MRFM that is fabricated and tested for this study is most suitable for light loads but can be sized up for applications that require supporting heavier equipment, such as automotive engine mounts. The mounts are unique in the sense that the MR fluid is used in the squeeze mode, which has not been studied as widely as the other modes, namely the valve and shear modes. The test results are compared with various mounts to enable directly assessing the contributions of the MR fluid and steel inserts that are needed for efficient magnetic flow through the fluid. For brevity, only the comparison between MRFM and the rubber mount was included in the paper with the intent to mainly highlight the benefits gained from MRFM, as compared with rubber mounts. The test results for a frequency band of 1 to 35 Hz show that the MRFM has slightly higher stiffness and nearly the same damping as a conventional rubber mount when no electrical current is supplied to it (i.e., the MR fluid is "off" or in its free-flowing state). The slight increase in MRFM stiffness is due to the MR fluid having a larger compressive stiffness than rubber. The stiffness and damping of the MRFM increase significantly at lower frequencies when a current is applied to it. The increase in both stiffness and damping is directly proportional to the supplied current. Ranging from 0.0 to 2.0 A, the supplied current contributes to increasing the MR fluid's yield stress, and its resistance to normal loads in the squeeze mode. Interestingly, this effect significantly tapers off at higher frequencies. For instance, for the 2 A supplied current, the test result indicates that MRFM has 200% higher stiffness and 700% higher damping than the rubber mount, at lower frequencies. However, its damping and stiffness are nearly the same as the rubber mount at higher frequencies (near 35 Hz.). The interesting and intriguing performance of MRFM make them an ideal vibration isolation device, in the sense that they offer high damping and stiffness when needed and taper off when lower damping and stiffness are desired.

Author Contributions: Conceptualization, M.A.; methodology, B.M.S.; software, B.M.S.; validation, M.A. and B.M.S.; formal analysis, B.M.S.; investigation, B.M.S.; resources, M.A.; data curation, B.M.S.; writing—original draft preparation, M.A.; writing—review and editing, M.A.; visualization, B.M.S.; supervision, M.A.; project administration, M.A.; funding acquisition, M.A. All authors have read and agreed to the published version of the manuscript.

Funding: This research received no external funding.

Institutional Review Board Statement: Not applicable.

Informed Consent Statement: Not applicable. **Data Availability Statement:** Not applicable.

Conflicts of Interest: The authors declare no conflict of interest.

References

- 1. Rabinow, J. The magnetic fluid clutch. AIEE Trans. 1948, 67, 1308.
- 2. Weiss, K.D.; Duclos, T.G.; Carlson, J.D.; Chrzan, M.J.; Margida, A.J. High strength Magneto– and Electro–Rheological Fluids. *SAE Trans.* **1993**, *102*, 425–430.
- 3. Carlson, J.D.; Weiss, K.D. A Growing Attraction to Magnetic Fluids. Mach. Des. 1994, 66, 61–64.

Fluids 2021, 6, 164 16 of 16

4. Goncalves, F.D. Characterizing the Behavior of Magnetorheological Fluids at High Velocities and High Shear Rates. Ph.D. Thesis, Virginia Polytechnic Institute and State University, Blacksburg, VA, USA, 2005.

- Crosby, M.J.; Karnopp, D.C. The Active Damper. In *The Shock and Vibration Bulletin 43*; Naval Research Laboratory: Washington, DC, USA, 1973.
- 6. Karnopp, D.C.; Crosby, M.J. System for Controlling the Transmission of Energy between Spaced Members. U.S. Patent 3,807,678, 30 April 1974.
- 7. Maddeh, A.A.; Hojjaf, Y.; Karafi, M.R.; Ashory, M.R. Reduction of Magneto Rheological Dampers Stiffness by Incorporating of an Eddy Current Damper. *J. Sounds Vib.* **2017**, 396, 51–68. [CrossRef]
- Simon, D.E. An Investigation of the Effectiveness of Skyhook Suspensions for Controlling Roll Dynamics of Sport Utility Vehicles
 Using Magnetorheological Dampers. Ph.D. Thesis, Virginia Polytechnic Institute and State University, Blacksburg, VA, USA, 2001.
- 9. Song, X.; Ahmadian, M.; Southward, S.C. An Adaptive Semiactive Control Algorithm for Vehicle Suspension Systems. In Proceedings of the IMECE, Washington, DC, USA, 16–21 November 2003.
- Phu, D.X.; Choi, S.-B. Magnetorheological Fluid Based Devices Reported in 2013–2018: Mini-Review and Comment on Structural Configurations. Front. Mater. 2019. [CrossRef]
- 11. Wei, M.; Rui, X.; Zhu, W.; Yang, F.; Gu, L.; Zhu, H. Design, Modelling and Testing of a Novel High-torque Magnetorheological Damper. *Smart Mater. Struct.* **2020**, *29*, 025024. [CrossRef]
- 12. Carlson, J.D. Multi-Degree of Freedom Magnetorheological Devices and System for Using Same. U.S. Patent 5,492,312, 20 February 1996.
- 13. Hong, S.R.; Choi, S.B.; Jung, W.J.; Jeong, W.B. Vibration isolation of Structural Systems Using Squeeze Mode ER Mounts. *J. Intell. Mater. Syst. Struct.* **2002**, *13*, 421–424. [CrossRef]
- 14. Deng, Z.; Yang, Q.; Zhao, S.; Wei, H. Multi-objective optimization of magneto-rheological mount structure based on vehicle vibration control. *J. Intell. Mater. Syst. Struct.* **2020**. [CrossRef]
- 15. Ahn, Y.K.; Kim, Y.C.; Yang, B.S.; Ahmadian, M. Optimal Design of Engine Mount Using an Enhanced Genetic Algorithm with Simplex Method. *Veh. Syst. Dyn.* **2005**, 43, 57–81. [CrossRef]
- 16. Christopherson, J.; Jazar, G.N. Dynamic Behavior Comparison of Passive Hydraulic Engine Mounts. Part 1: Mathematical analysis. *J. Sound Vib.* **2005**, 290, 1040–1070. [CrossRef]
- 17. Ahn, Y.K.; Kim, Y.; Yang, B.; Ahmadian, M.; Baek, W.K. Optimal Design of Engine Mount Using an Enhanced Genetic Algorithm and Simplex Method. In Proceedings of the 8th International Congress on Sound and Vibration, Hong Kong, China, 2–6 July 2001.
- 18. Koo, J.H.; Ahmadian, M.; Setareh, M.; Murray, T.M. In Search of Suitable Control Methods for Semi-Active Tuned Vibration Absorbers. *J. Vib. Control* **2004**, *10*, 163–174. [CrossRef]
- 19. Boczkowska, A.; Awietjan, S.F.; Wroblewski, R. Microstructure-property Relationships of Urethane Magnetorheological Elastomers. *Smart Mater. Struct.* **2007**, *16*, 1924–1930. [CrossRef]
- Wang, X.; Gordaninejad, F.; Hitchcock, G. A Dynamic Behaviors of Magneto-Rheological Fluid-elastomer Composites under Oscillatory Compression. Damping and Isolation. Conference on Smart Materials and Structures. Proc. SPIE 2004, 5386, 250–258.
- 21. Wang, X.; Gordaninejad, F.; Hitchcock, G. A Magneto-rheological Fluid Elastomer Vibration Isolator. Smart Structures and Materials. *Proc. SPIE* **2005**, *5760*, 217–225.
- 22. York, D.; Wang, X.; Gordaninejad, F. A New MRF-E Vibration Isolator. J. Intell. Mater. Syst. Struct. 2007, 18, 1221–1225. [CrossRef]
- 23. Gordaninejad, F.; Fuchs, A.; Wang, X.; Hitchcock, G.H.; Xin, M. Magneto-rheological Fluid Encased in Flexible Materials for Vibration Control. U.S. Patent 6,971,491B1, 6 December 2005.
- 24. Hua, D.; Liu, X.; Li, Z.; Fracz, P.; Hnydiuk-Stefan, A.; Li, Z. A Review on Structural Configurations of Magnetorheological Fluid Based Devices Reported in 2018–2020. *Front. Fluid* **2021**. [CrossRef]
- 25. Kavlicoglu, B.; Liu, Y.; Wallis, B.; Sahin, H.; McKee, M.; Gordaninejad, F. Two-way controllable magnetorheological elastomer mount for shock and vibration mitigation. *Smart Mater. Struct.* **2020**. [CrossRef]
- 26. Jalali, A.; Dianati, H.; Norouzi, M. A novel bi-directional shear mode magneto-rheological elastomer vibration isolator. *J. Intell. Mater. Struct.* **2020**. [CrossRef]
- 27. Southern, B.M. Design and Characterization of Tunable Magneto-Rheological Fluid-Elastic Mounts. Master's Thesis, Virginia Polytechnic Institute and State University, Blacksburg, VA, USA, 2008.
- 28. Carlson, J.D. MR Fluids and Devices in the Real World. Int. J. Mod. Phys. B 2005, 19, 1463–1470. [CrossRef]