


Molecules **1999**, *4*, M121

3a,4,5,6,7,8,9,10,11,12,13,13a-Dodecahydro-3-(4-chlorophenyl)cyclododeca[d]isoxazole

Bruce A. Hathaway and Ryan A. Mueller

Department of Chemistry, Southeast Missouri State University, MS 6400, One University Plaza, Cape Girardeau, Missouri, 63701, USA. Tel. 001 573-651-2370; Fax 001 573-986-6433; E-mail: bahathaway@semovm.semo.edu

Received: 22 October 1999 / Accepted: 1 November 1999 / Published: 23 November 1999



To a solution of 4-chlorobenzaldehyde oxime (0.40g) in CH₂Cl₂ (10 mL) in a large test-tube were added 1.0 mL of cyclododecene and 3 drops of triethylamine. The solution was cooled to 5°C, then 7.0 mL of 5% NaOCl solution in water was added in small portions. After each portion was added, the test-tube was agitated with a VibromixerTM stirrer for 15 seconds. After the addition of all of the NaOCl solution, the test-tube was agitated with a VibromixerTM stirrer for 15 seconds every 5 minutes over the next hour. The reaction mixture was allowed to stand at least overnight. The layers were separated, and the aqueous layer was extracted with CH₂Cl₂ (5 mL). The combined CH₂Cl₂ layers were evaporated to yield an off-white solid. The solid was recrystallized from 95% ethanol to yield shiny white flakes. Yield: 0.24g (29%).

M.p. 118-119°C.

IR (KBr pellet, cm⁻¹): 2936, 2855, 1590, 1494, 1469, 1446, 1404, 1346, 1093, 901, 868, 832.

¹H-NMR (300MHz, CDCl₃, ppm): 1.35-1.65 (20 H, multiplets), 3.48 (1H, d of m), 4.76 (1H, d of m), 7.38 (2H, m), 7.64 (2H, m).

¹³C-NMR (75.5 MHz, CDCl₃, ppm): 159.0, 136.0, 129.4, 128.5, 128.2, 84.5, 48.4, 31.9, 29.9, 27.3, 27.1, 24.0, 23.4, 23.0, 22.4, 22.06, 22.00.

GC-MS (ion trap, m/e, in order of decreasing peak size): 137 (100%), 102, 50, 75, 139, 51, very small molecular ion at 319/321 detected.

References

- Gingrich, H. L.; Pickering, M. *J. Chem. Educ.* **1991**, *68*, 614-615.
- Bianchi, G.; De Micheli, C.; Gandolfi, R. *J. Chem. Soc., Perkin Trans. 1* **1972**, 1711-1714.

Sample Availability: available from MDPI.

©1999 MDPI. All rights reserved. *Molecules* website www.mdpi.org/molecules