

**Supporting information to**

**Characterisation of natural fibres for sustainable discontinuous fibre composite materials**


Ali Kandemir\*, Thomas R. Pozegic, Ian Hamerton, Steve J. Eichhorn, Marco L. Longana

Bristol Composites Institute (ACCIS), Department of Aerospace Engineering, University of Bristol, Bristol, BS8 1TR, UK


\*e-mail address: ali.kandemir@bristol.ac.uk

**Failure types during IFSS test**


Following figures (S1-S5) show examples of the failure types (IFSS, Fibrillation, FFD, FF, and MB) observed in IFSS tests. It is important to check droplet position before test to decide failure type, especially for IFSS since it may be deceptive to check only test data.




**Decision: IFSS (valid interfacial failure, as the droplet slides to another position)**




**Figure S1.** IFSS failure.




**Decision: Fibrillation (the droplet slid to another position, but fibrillation observed)**




**Figure S2.** Fibrillation failure.




**Decision: FFD (fibre failure by the droplet)**




**Figure S3.** FFD failure.




**Decision: FF (fibre failure)**



**Figure S4.** FF failure.



**Decision: MB (broken matrix, the droplet did not slide)**



**Figure S5.** MB failure.

### The isothermal TGA test

Figure S6 shows temperature profile during the isothermal TGAs. As seen in the figure, +10°C temperature strike happened during the tests and the fibres were exposed to over temperature until the last 30 minutes of the tests.




Figure S6. Temperature profile as a function of time during isothermal heating at 175°C and 225°C.