













Supporting Materials

Attachment S1 (1-13 pages): Cura slicer's setting options

Settings of Cura software including options found from the dropdown menu (▼).

Quality ▼		
Layer Height		0.1 mm
Initial Layer Height		0.2 mm
Line Width		0.4 mm
Wall Line Width		0.4 mm
Outer Wall Line Width		0.4 mm
Inner Wall(s) Line Width		0.4 mm
Top/Bottom Line Width		0.4 mm
Infill Line Width		0.5 mm
Skirt/Brim Line Width		0.4 mm
Prime Tower Line Width		0.4 mm
Initial Layer Line Width		120 %

 Shell 	
Wall Extruder	 Not overridden 
Outer Wall Extruder	 Not overridden 
Inner Wall Extruder	 Not overridden 
Wall Thickness	1.3 mm
Wall Line Count	3
Outer Wall Wipe Distance	0.2 mm
Top Surface Skin Layers	0
Top/Bottom Extruder	 Not overridden 
Top/Bottom Thickness	1.2 mm
Top Thickness	1.2 mm
Top Layers	12
Bottom Thickness	1.2 mm
Bottom Layers	12
Initial Bottom Layers	12
Top/Bottom Pattern	Lines 
Bottom Pattern Initial Layer	Lines 
Top/Bottom Line Directions	[]

Outer Wall Inset	<input type="text" value="0"/> mm
Optimize Wall Printing Order	<input checked="" type="checkbox"/>
Outer Before Inner Walls	<input type="checkbox"/>
Alternate Extra Wall	<input type="checkbox"/>
Compensate Wall Overlaps	<input checked="" type="checkbox"/>
Compensate Outer Wall Overlaps	<input checked="" type="checkbox"/>
Compensate Inner Wall Overlaps	<input checked="" type="checkbox"/>
Minimum Wall Flow	<input type="text" value="0"/> %
Fill Gaps Between Walls	<input type="text" value="Everywhere"/> ▼
Filter Out Tiny Gaps	<input checked="" type="checkbox"/>
Print Thin Walls	<input type="checkbox"/>
Horizontal Expansion	<input type="text" value="0"/> mm
Initial Layer Horizontal Expansion	<input type="text" value="0"/> mm
Hole Horizontal Expansion	<input type="text" value="0"/> mm
Z Seam Alignment	<input type="text" value="Sharpest Corner"/> ▼
Seam Corner Preference	<input type="text" value="Hide Seam"/> ▼
No Skin in Z Gaps	<input type="checkbox"/>
Extra Skin Wall Count	<input type="text" value="1"/>
Enable Ironing	<input type="checkbox"/>
Skin Overlap Percentage	<input type="text" value="50"/> %
Skin Overlap	<input type="text" value="0.2"/> mm

Infill	
Infill Extruder	Not overridden
Infill Density	20 %
Infill Line Distance	7.5 mm
Infill Pattern	Triangles
Connect Infill Lines	<input checked="" type="checkbox"/>
Infill Line Directions	[]
Infill X Offset	0 mm
Infill Y Offset	0 mm
Randomize Infill Start	<input type="checkbox"/>
Infill Line Multiplier	1
Extra Infill Wall Count	0
Infill Overlap Percentage	0 %
Infill Overlap	0.0 mm
Infill Wipe Distance	0 mm
Infill Layer Thickness	0.1 mm
Gradual Infill Steps	0
Infill Before Walls	<input checked="" type="checkbox"/>
Minimum Infill Area	0 mm ²
Infill Support	<input type="checkbox"/>
Skin Removal Width	1.2 mm
Top Skin Removal Width	1.2 mm
Bottom Skin Removal Width	1.2 mm
Skin Expand Distance	1.2 mm
Top Skin Expand Distance	1.2 mm
Bottom Skin Expand Distance	1.2 mm
Maximum Skin Angle for Expansion	90 °
Minimum Skin Width for Expansion	0.0 mm
Skin Edge Support Thickness	0 mm
Skin Edge Support Layers	0

Grid

Lines

Triangles

Tri-Hexagon

Cubic

Cubic Subdivision

Octet

Quarter Cubic

Concentric

Zig Zag




Cross






Cross 3D

Gyroid

Triangles

☒


Material		
Build Volume Temperature		28 °C
Printing Temperature		245 °C
Printing Temperature Initial Layer		245 °C
Initial Printing Temperature		240 °C
Final Printing Temperature		235 °C
Extrusion Cool Down Speed Modifier		0.7 °C/s
Build Plate Temperature		70 °C
Build Plate Temperature Initial Layer		70 °C
Flow		100 %
Wall Flow		100 %
Outer Wall Flow		100 %
Inner Wall(s) Flow		100 %
Top/Bottom Flow		100 %
Infill Flow		100 %
Skirt/Brim Flow		100 %
Prime Tower Flow		100 %
Initial Layer Flow		100 %
Standby Temperature		100 °C
Speed		
Print Speed		70 mm/s
Infill Speed		70 mm/s
Wall Speed		30 mm/s
Outer Wall Speed		20 mm/s
Inner Wall Speed		30 mm/s
Top/Bottom Speed		30 mm/s
Prime Tower Speed		30 mm/s

Travel Speed		150	mm/s
Initial Layer Speed		20	mm/s
Initial Layer Print Speed		20	mm/s
Initial Layer Travel Speed		42.8571	mm/s
Skirt/Brim Speed		20	mm/s
Z Hop Speed		10	mm/s
Number of Slower Layers		2	
Equalize Filament Flow		<input checked="" type="checkbox"/>	
Maximum Speed for Flow Equalization		150	mm/s
Enable Acceleration Control		<input checked="" type="checkbox"/>	
Print Acceleration		4000	mm/s ²
Infill Acceleration		4000	mm/s ²
Wall Acceleration		1000	mm/s ²
Outer Wall Acceleration		500	mm/s ²
Inner Wall Acceleration		1000	mm/s ²
Top/Bottom Acceleration		500	mm/s ²
Prime Tower Acceleration		2000	mm/s ²
Travel Acceleration		5000	mm/s ²
Initial Layer Acceleration		500	mm/s ²
Initial Layer Print Acceleration		500	mm/s ²
Initial Layer Travel Acceleration		625.0	mm/s ²
Skirt/Brim Acceleration		500	mm/s ²
Enable Jerk Control		<input checked="" type="checkbox"/>	
Print Jerk		25	mm/s
Infill Jerk		25	mm/s
Wall Jerk		10	mm/s


Outer Wall Jerk		5	mm/s
Inner Wall Jerk		10	mm/s
Top/Bottom Jerk		5	mm/s
Prime Tower Jerk		15	mm/s
Travel Jerk		50	mm/s
Initial Layer Jerk		5	mm/s
Initial Layer Print Jerk		5	mm/s
Initial Layer Travel Jerk		10.0	mm/s
Skirt/Brim Jerk		5	mm/s

























Travel

Enable Retraction	<input checked="" type="checkbox"/>
Retract at Layer Change	<input type="checkbox"/>
Retraction Distance	8 mm
Retraction Speed	25 mm/s
Retraction Retract Speed	25 mm/s
Retraction Prime Speed	25 mm/s
Retraction Extra Prime Amount	0 mm ³
Retraction Minimum Travel	0.8 mm
Maximum Retraction Count	25
Minimum Extrusion Distance Window	1 mm
Combing Mode	All
Max Comb Distance With No Retract	0 mm
Retract Before Outer Wall	<input type="checkbox"/>
Avoid Printed Parts When Traveling	<input checked="" type="checkbox"/>
Avoid Supports When Traveling	<input checked="" type="checkbox"/>
Travel Avoid Distance	3 mm
Layer Start X	330.0 mm
Layer Start Y	228.0 mm
Z Hop When Retracted	<input checked="" type="checkbox"/>
Z Hop Only Over Printed Parts	<input checked="" type="checkbox"/>
Z Hop Height	2 mm
Z Hop After Extruder Switch	<input checked="" type="checkbox"/>
Z Hop After Extruder Switch Height	2 mm


Cooling
▼

Enable Print Cooling	<input checked="" type="checkbox"/>
Fan Speed	40 %
Regular Fan Speed	40 %
Maximum Fan Speed	100 %
Regular/Maximum Fan Speed Threshold	20 s
Initial Fan Speed	0 %
Regular Fan Speed at Height	0.6 mm
Regular Fan Speed at Layer	6
Minimum Layer Time	5 s
Minimum Speed	12 mm/s
Lift Head	<input type="checkbox"/>


Support
⚙️ ▼
















Generate Support	 	<input checked="" type="checkbox"/>
Support Extruder		Extruder 1 
Support Infill Extruder		Extruder 1 
First Layer Support Extruder		Extruder 1 
Support Interface Extruder		Extruder 1 
Support Roof Extruder		Extruder 1 
Support Floor Extruder		Extruder 1 
Support Placement		Everywhere 
Support Overhang Angle		60 °
Support Pattern		Zig Zag 
Support Wall Line Count		0
Connect Support ZigZags		<input checked="" type="checkbox"/>
Support Density		15 %
Support Line Distance		2.6667 mm
Initial Layer Support Line Distance		2.6667 mm

Support Infill Line Directions		[]
Enable Support Brim		<input type="checkbox"/>
Support Z Distance		0.2 mm
Support Top Distance		0.2 mm
Support Bottom Distance		0.1 mm
Support X/Y Distance		1.0 mm
Support Distance Priority		Z overrides X/Y ▼
Minimum Support X/Y Distance		0.4 mm
Support Stair Step Height		0.3 mm
Support Stair Step Maximum Width		5.0 mm
Support Join Distance		2.0 mm
Support Horizontal Expansion		0 mm
Support Infill Layer Thickness		0.1 mm
Gradual Support Infill Steps		0
Minimum Support Area		0.0 mm ²
Enable Support Interface		<input type="checkbox"/>
Enable Support Roof		<input type="checkbox"/>
Enable Support Floor		<input type="checkbox"/>
Fan Speed Override		<input type="checkbox"/>
Use Towers		<input checked="" type="checkbox"/>
Tower Diameter		3.0 mm
Maximum Tower-Supported Diameter		3.0 mm
Tower Roof Angle		65 °
⚙️ Build Plate Adhesion ▼		
Enable Prime Blob		<input type="checkbox"/>
Build Plate Adhesion Type		Brim ▼
Build Plate Adhesion Extruder		Extruder 1 ▼
Skirt/Brim Minimum Length		250 mm
Brim Width		7 mm
Brim Line Count		15
Brim Distance		0 mm
Brim Replaces Support		<input checked="" type="checkbox"/>
Brim Only on Outside		<input checked="" type="checkbox"/>










Experimental		
Tree Support		<input type="checkbox"/>
Slicing Tolerance		Middle
Infill Travel Optimization		<input type="checkbox"/>
Minimum Polygon Circumference		1.0 mm
Break Up Support In Chunks		<input type="checkbox"/>
Enable Draft Shield		<input type="checkbox"/>
Make Overhang Printable		<input type="checkbox"/>
Enable Coasting		<input type="checkbox"/>
<hr/>		
Spaghetti Infill		<input type="checkbox"/>
Enable Conical Support		<input type="checkbox"/>
Fuzzy Skin		<input type="checkbox"/>
Flow Rate Compensat...ax Extrusion Offset		0 mm
Flow Rate Compensation Factor		100 %
Wire Printing		<input type="checkbox"/>
Use Adaptive Layers		<input type="checkbox"/>
Overhanging Wall Angle		90 °
Overhanging Wall Speed		100 %
Enable Bridge Settings		<input type="checkbox"/>
Wipe Nozzle Between Layers		<input type="checkbox"/>
Small Hole Max Size		0 mm
Small Feature Max Length		0.0 mm
Small Feature Speed		50 %
Small Feature Initial Layer Speed		50 %

List materials


Generic

-  Generic ABS
-  Generic Breakaway
-  Generic CFF CPE
-  Generic CFF PA
-  Generic CPE
-  Generic CPE+
-  Generic GFF CPE
-  Generic GFF PA
-  Generic Nylon
-  Generic PC
-  Generic PLA
-  Generic PP
-  Generic PVA
-  Generic Tough PLA
-  Generic TPU 95A

ABS

-  Ultimaker Black ABS
-  Ultimaker Blue ABS
-  Ultimaker Green ABS
-  Ultimaker Grey ABS
-  Ultimaker Orange ABS
-  Ultimaker Pearl Gold ABS
-  Ultimaker Red ABS
-  Ultimaker Silver Metallic ABS
-  Ultimaker White ABS
-  Ultimaker Yellow ABS


Breakaway

-  Ultimaker White Breakaway


CPE

-  Ultimaker Black CPE
-  Ultimaker Blue CPE
-  Ultimaker Dark Grey CPE
-  Ultimaker Green CPE
-  Ultimaker Light Grey CPE
-  Ultimaker Red CPE
-  Ultimaker Transparent CPE
-  Ultimaker White CPE
-  Ultimaker Yellow CPE





PP

-  Ultimaker Transparent PP



PVA

-  Ultimaker Natural PVA

Tough PLA

-  Ultimaker Black Tough PLA
-  Ultimaker Green Tough PLA
-  Ultimaker Red Tough PLA
-  Ultimaker White Tough PLA




TPU 95A

-  Ultimaker Black TPU 95A
-  Ultimaker Blue TPU 95A
-  Ultimaker Red TPU 95A
-  Ultimaker White TPU 95A

Attachment S2: software limitation (pages 14-15)

The thickness of original model was 3 mm composed of 30 layers using 0.100 mm thickness option. Using ‘raise part’ option that uses 20 plastic layers (50 layers now) before it starts printing the main model to get better part quality (just in case, sometime if first few floor layers may not be of desired quality). Unfortunately, the following Figures demonstrate how the first two plastic layers experienced undesirable topology, which as not the part the model, and therefore, it negatively impacts the part quality.

Table S1: 2D layers view availed from the Eiger slicer

Category	Stacking of the layers	2D views from the slicing software
First 20 layers for ‘raise part’	Layers 1-16	
	Layers 17-18	Now these two layers are same as 1-16 layers. Previously, they were like the following image, 
	Layers 19-20	Previously it showed nothing, now it shows following, respectively 
Main part	Two undesirable layers, which was not planned to associate to the main part 1-21	









	(first two layers of the main part)		
	Rest are as planned ($\pm 45^\circ$ plastic layers and other planned fiber layer orientations)	45 plastic layers 	

Table S2: Different views of the printed part using raise part option and regular part (without using 'raise part' option)

Category	Top (roof)	Bottom (floor)	Side
Using 'raise part' option			
Regular part, without 'raise part' option			

Attachment S3: importance of flatness of the print bed (pages 16-18)

Bed leveling knobs:




Figure S1: Three bed leveling knobs at three concerns, two at the front in either ends and one at the back in the middle

Bed level test print:




Figure S2: An example of uneven print bed. Although the bed level test at three corners shows good sign of leveling, the middle one suffers from low bed level that indicates imperfection in the flatness

Example of effect of uneven bed




Figure S3: The effect of uneven bed (the images were taken after printing first layer, 0.1 mm thickness), printed good at some areas (a), with disjoint beads at some area (b) and with almost no materials at some area (c) (also a very good example of under extrusion due to printing with less material)

Attachment S4: print bead density for different materials layer heights (pages 19-20)

How is bead density; if the print layer height and using different materials affect the bead density so as the integrity of printed composites. Printed beads were counted by intentionally lowering the print bed so that it prints disconnected print beads

Table S3: Plastic layer bead density for 30 mm X 30 mm sample with 1 wall layer






Views	Layer height (0.1, 0.125 and 0.2 mm)	
	Eiger software	Printed layer
For floor/roof		
For infill		

Table S4: Fiber layer bead density for 30 mm X 30 mm sample with 1 wall layer

Fiberglass (0.1 mm layer height)	Carbon fiber (0.125 mm layer height)
	



0.1 mm layer height



0.125 mm layer height



0.2 mm layer height

Figure S4: First layer views at different layer heights indicating relative increment of coverage of gaps at the same bed level